


MODEL 184 LO-BOY TRACTOR
12 VOLT BATTERY IGNITION

CUBCADETPARTSNMORE.COM
515-266-7944



KEY SWITCH

OFF	NONE
RUN	B+I
START	B+I+S