


NOTE: (A.) Fuse Supplied By Operator

1. Right Hazard Light
2. Right Reverse Light
3. Right Tail Light
4. Left Tail Light
5. Left Reverse Light
6. Left Hazard Light



MODEL 7254 ENGINE HARNESS

629-3063

