



PTO SWITCH	
OFF	C+D
ON	B+A
START	B+A+F

KEY SWITCH	
OFF	M+GROUND
RUN w/LIGHTS	B+R+L
RUN	B+R
START	B+S

**MODEL 1812**  
**SERIAL NUMBER (750,127 - 756,999)**