


Cub Cadet®

PARTS MANUAL



Zero Turn Riding Mower


Models

i1046

i1050

CUB CADET LLC, P.O. BOX 361131 CLEVELAND, OHIO 44136-0019

Frame, PTO & Battery




Frame, PTO & Battery

Ref. No.	Part No.	Description
1	683-04305	Frame Assembly
2	683-04333	Frame Assembly, Seat
3	683-04351	Bracket, Running Board Support
4	710-0451	Screw, Carriage, 5/16-18 x .75 Gr.1
5	710-0599	Screw, Hex Wash. Hd. Tapp, 1/4-20 x .5
6	710-04666	Screw, Hex Flange Hd. , 1/4-20 x .75 Gr5
7	710-0726	Screw, Hex Wash. Hd. Tapp, 5/16-12 x .75
8	710-0642	Screw, Hex Wash. Hd. Tapp, 1/4-20 x .75
9	710-04379A	Screw, Hex Cap Lock, 7/16-20 x 3.5 Gr5
10	710-1260A	Screw, Hex Wash. Hd. Tapp, 5/16-18 x .75
11	710-3005	Screw, Hex Cap, 3/8-16 x 1.25 Gr5
12	712-0271	Nut, Hex Sems, 1/4-20
13	712-3087	Nut, Wing, 1/4-20
14	712-04063	Nut, Hex Flange Insert Lock, 5/16-18
15	712-04064	Nut, Hex Flange Insert Lock, 1/4-20 GrF
16	712-04065	Nut, Hex Flange Insert Lock, 3/8-16 GrF
17	717-04174A	Clutch, Electric PTO
18	725-04439	Solenoid, Start
19	731-05659	Bushing, Steering Shaft
20	736-0171	Washer, Lock, 7/16

Ref. No.	Part No.	Description
21	736-0222	Washer, External Lock, 1/4
22	738-0143	Bolt, Shoulder, .496 x .336:3/8-16
23	738-1132	Screw, Shoulder, .25 x .15:1/4-20
24	738-04058	Screw, Shoulder, .38 x 1.0 x .7
25	747-04215	Strap, Battery
26	750-04763	Spacer, 1.37 x 1.00 x .25
27	756-0978B	Pulley, Engine
28	783-1447C	Bracket, Battery Support
29	783-04419B	Bracket, Clutch
30	783-04467	Bracket, Deck Up Stop
31	783-04806	Bracket, Pivot Bar
32	783-04844	Bracket, Pivot Support RH
33	783-04845	Bracket, Pivot Support LH
34	783-04868	Bracket, Steering Support
35	783-04910	Bracket, Support Fender
36	925-1707D	Battery - Dry
37	725-04513	Wire, Ground Jumper
38	725-0157	Cable Tie
	725-04375A	Harness, Main Wire

Hood, Dash Panel & Fuel Tank




Hood, Dash Panel & Fuel Tank

Ref. No.	Part No.	Description
1	683-04219A	Bumper Assembly
2	710-0192	Screw, Truss Hd. Mach., 10-24 x .375
3	710-0599	Screw, Hex Wash Hd. Tapp, 1/4-20 x .5
4	710-0604A	Screw, Hex Wash Hd. Tapp, 5/16-18 x .625
5	710-0607	Screw, Hex Wash Hd. Tapp, 5/16-18 x .5
6	710-0642	Screw, Hex Wash Hd. Tapp, 1/4-20 x .75
7	710-0726	Screw, Hex Wash Hd. Tapp, 5/16-12 x .75
8	710-0895	Screw, Hex Wash Hd. Tapp, 1/4-15 x .75
9	710-1611B	Screw, Pan Hd. Tapp, 5/16-18 x .75
10	710-3217	Screw, Truss Hd. Mach., #8-32 x .375
11	712-0142	Nut, Hex, 8-32
12	712-04065	Nut, Hex Flange Insert Lock, 3/8-16 GrF
13	725-0157	Tie, Cable
14	725-0963	Bulb, 12V Light
15	725-1649	Receptacle, Light
16	725-2003	Receptacle, 12V Power
17	725-2054	Key, Ignition Switch
18	725-04022B	Meter, Indicator/Service Monitor
19	725-04258	Switch, PTO
20	725-04227	Switch, Ignition/Module
21	726-3046	Clip, Ratchet
22	731-04213	Lever, Dash Brake
23	731-05368	Cap, Bumper
24	731-05406	Panel, Dash
25	731-05434	Hood
26	731-05435	Plenum, Hood
27	731-05525	Lense, Head Light LH

Ref. No.	Part No.	Description
28	731-05526	Lense, Head Light RH
29	731-3161A	Knob, Throttle Control
30	735-0271A	Bumper
31	735-04075	Deflector, Rubber Hood
32	735-04076	Net, Storage
33	736-0463	Washer, Flat, .25 x .63 x .0515
34	738-0143	Bolt, Shoulder, .496 x .336:3/8-16
35	738-04091	Screw, Shoulder, .43 x .29:TT5/16-18
36	746-1100	Cable, Throttle Control
37	746-04120	Cable, Choke Control
38	747-1155	Rod, Brake Lock Pivot
39	777X42426	Label, Reflector
40	777X42427	Label, Reflector
41	783-04285D	Support, Dash, R.H.
42	783-04323D	Support, Dash, L.H.
43	783-04506A	Plate, Dash Support
44	783-04606B	Bracket, Hood Pivot
45	783-04840	Bracket, Hood Pivot RH
46	783-04841	Bracket, Hood Pivot LH
47	783-05162	Bracket, Hood Support
48	651-04174	Tank Assembly, Fuel
49	735-0149	Bushing, Fuel Tank
50	735-04081	Grommet, Rubber
51	751-10441	Valve, Rollover
52	751-10442	Fitting, Fuel Pick Up
53	751-10447	Cap, Fuel Tank

Seat, Fender & Deck Lift




Seat, Fender & Deck Lift

Ref. No.	Part No.	Description
1	17239D	Bracket, Seat Switch
2	647-04095	Shaft, Lift
3	683-04313	Seat Slide
4	710-04482	Screw, Hex Flange, 3/8-16 x .875 Gr5
5	710-1260A	Screw, Hex Wash Hd. Tapp, 5/16-18 x .75
6	710-0451	Screw, Carriage, 5/16-18 x 75
7	710-0599	Screw, Hex Wash Hd. Tapp, 1/4-20 x .5
8	710-0726	Screw, Hex Wash Hd. Tapp, 5/16-12 x .75
9	710-0895	Screw, Hex Wash Hd. Tapp, 1/4-15 x .75
10	711-0332	Pin, Clevis, .5 x .78
11	711-04626	Pin, Seat Index
12	712-04063	Nut, Hex Flange Insert Lock, 5/16-18 GrF
13	712-04065	Nut, Hex Flange Insert Lock, 3/8-16 GrF
14	710-04187	Screw, Hex Wash Hd. H/L, 1/4-15 x .5
15	714-0104	Pin, Internal Cotter
16	714-0111	Pin, Cotter, 3/32 x 1.0
17	714-04023	Pin, Internal Cotter
18	716-0106A	E-ring, .625 Shaft
19	720-0311	Grip, Handle
20	726-3046	Clip, Ratchet
21	731-04074	Spacer, Seat Adjustment
22	731-05477	Cover, Rear Fender RH
23	731-05518	Cover, Rear Fender LH
24	732-04074	Spring, Compression
25	732-04386	Spring, Seat Adjust
26	732-04442	Spring, Lift Torsion
27	732-0826A	Spring, Extension, .865 x 4.68
28	732-1184	Spring, Extension, .84 x 4.6

Ref. No.	Part No.	Description
29	735-04078	Pad, Foot RH
30	735-04079	Pad, Foot LH
31	726-0221	Nut, Speed, .5
32	736-0272	Washer, Flat, .51 x 1.0 x .06
34	736-0192	Washer, Flat, .535 x .93 x .09
35	736-3078	Washer, Flat, .344 x 1.0 x .063 HT
36	738-0138A	Bolt, Shoulder, .496 x 2.5:3/8-16
37	738-0380	Bolt, Shoulder, .5 x .27:3/8-16
38	738-0966A	Bolt, Shoulder, .5 x .925:3/8-16
39	738-1011A	Bolt, Shoulder, .5 x 2.23:3/8-16
40	738-0296	Bolt, Shoulder, .447 x .268:5/16-18
41	741-0225	Bearing, Hex Flange,
42	746-04369	Cable, Lift, 16.16 Lg
43	746-0968	Cable, Lift, 16.16 Lg
44	747-04613	Handle, Lift
45	756-1154	Pulley, Roller
46	757-04053	Seat, High Back
47	783-0678B	Link, Deck Lift
48	783-0720C	Bracket, Front Deck Adjust
49	783-04901	Fender, Rear
50	783-04977A	Plate, Deck Lift
51	783-05307	Pedesta, Seat
52	783-05272	Plate, Seat Pivot
53	710-0227	Screw, Hex Wash Hd. Tapp, #8-18 x .5
54	726-0279	Plate, Insulator
55	725-1303	Switch, Outer Seat Spring
56	725-1439	Switch, Inner Seat Spring
57	726-0278	Plate, Insulator Boss

Steering Controls & Front Axle




Steering Controls & Front Axle

Ref. No.	Part No.	Description
1	618-04430	Steering Assembly, Steering/Hydro
2	631-04008A	Wheel Assembly, Steering
3	N/A 734-1731 737-0224 941-04137 934-0255 634-04104A	Wheel Assembly Tire, 15 x 6 x 6 Grease Fitting Bearing, Ball Valve, Tubeless Air Rim Assembly
4	647-04062	Axle Assembly, LH
5	647-04063	Axle Assembly, RH
6	647-04080A	Rod, Fender Support
7	710-0599	Screw, Hex Wash Hd. Tapp, 1/4-20 x .5
8	683-04282A	Arm, Steering, RH
9	683-04284A	Arm, Steering, LH
10	683-04332	Link, Steering Box/Hydro
11	710-0597	Screw, Hex Cap, 1/4-20 x 1.0 Gr5
12	710-0195	Screw, Hex Cap, 1/4-28 x .625 Gr5
13	710-0528	Screw, Hex Cap, 5/16-18 x 1.25 Gr5
14	710-0642	Screw, Hex Wash Hd. Tapp, 1/4-20 x .75
15	710-0650	Screw, Hex Wash Hd. Tapp, 5/16-18 x .875
16	710-04187	Screw, Hex Wash Hd. Hi/Lo, 1/4-15 x .5
17	710-3015	Screw, Hex Cap, 1/4-20 x .75 Gr5
18	710-0520	Screw, Hex Cap, 3/8-16 x 1.5 Gr5
19	710-3085	Screw, Hex Cap, 3/8-16 x 3.5 Gr5
20	710-3119	Screw, Hex Cap Lock, 3/8-16 x .75 Gr5
21	710-3144	Screw, Hex Cap, 3/8-16 x 2.0 Gr5
22	710-3296	Screw, Hex Cap Lock, 1/4-20 x .75 Gr5
23	710-04006	Screw, Hex Wash Hd. Tapp, 5/16-18 x 2.0
24	710-04389	Screw, Hex Wash Hd. Tapp, 5/16-18 x 2.25
25	710-1260A	Screw, Hex Wash Hd. Tapp, 5/16-18 x .75
26	711-04722	Pin, Clevis, .375 x .969 HT
27	711-04472	Link, Drag
28	711-04562	Shaft, Steering Pivot Gear
29	712-0312A	Nut, Jam, 3/8-24 LH Thrd
30	712-0365	Nut, Hex Lock, M8 x 1.25 Gr9
31	712-0375	Nut, Hex Lock, 3/8-16
32	712-04063	Nut, Hex Insert Flange Lock, 5/16-18 GrF
33	712-04064	Nut, Hex Insert Flange Lock, 1/4-20 GrF
34	712-04065	Nut, Hex Insert Flange Lock, 3/16-16 GrF
35	712-3001	Nut, Hex Jam, 3/8-24 Gr2

Ref. No.	Part No.	Description
36	713-04037	Link, Connecting
37	714-0104	Pin, Internal Cotter
38	736-0286	Washer, Sping, .39 x .75 x .010
39	714-04039	Pin, Cotter, 5/32 x 1.25
40	717-04274	Gear, Spur, 12T
41	717-04275	Gear, Spur, RH 13T
42	717-04282	Gear, Spur, LH 13T
43	719-04170	Axle, Pivot Bar
44	723-04035	End, Ball Joint Rod
45	723-04036	End, Ball Joint Rod, LH Thrd.
46	737-3000	Fitting, Grease
47	727-0626A	Cylinder, Damper
48	731-04532	Cover, Steering Wheel
49	731-05476	Cover, Steering Gear, RH
50	731-05618	Cover, Steering Gear, LH
51	736-0185	Washer, Flat, .375 x .738.063
52	736-0270	Washer, Bell, .265 x .75 x .062
53	736-0315	Washer, Flat, .76 x 1.5 x .12
54	736-0866	Washer, Flat, .755 x 1.92 x .060
55	736-0452	Washer, Bell, .396 x 1.14 x .095
56	736-3004	Washer, Flat, .406 x .875 x .105
57	738-04189	Shaft, Steering, .625 x 17.281
58	738-04240	Nut, Shoulder, .375 x .5
59	747-04496	Rod, 3/8-24 x 14.4 Lg
60	748-04139	Block, Steering Shaft
61	750-04676	Spacer, .385 x .63 x .75
62	750-04776	Spacer, .380 x .625 x .265
63	750-04777	Spacer, .26 x .372 x .33
64	783-04798	Bracket, Steering Support, LH
65	783-04799	Bracket, Steering Support, Upper
66	783-05140	Bracket, Steering Support, RH
67	783-05184	Plate, Base Cover, RH
68	783-05185	Plate, Base Cover, LH
69	783-05380	Link, Steering/Hydro RH
70	783-05381	Bracket, Hydro/Steering Adjustment
71	783-05404	Link, Steering/Hydro LH
72	783-05446	Bracket, Steering Link
73	731-3020	Hub Cap

Transmission Drive & Controls




Transmission Drive & Controls

Ref. No.	Part No.	Description
1	17840	Bracket, Transmission Mounting
2	618-04317	Hub, Wheel
3	N/A 734-1730 934-0255 634-0246A	Wheel Assembly Tire, 20 x 8 x 8 Valve, Tubeless Air Rim Assembly, Rear
4	647-04061	Shaft Assembly, Brake Control
5	647-04094	Shaft Assembly, Hydro Control Pedal
6	683-0267C	Pedal Assembly, Hydro Control
7	683-04314A	Bracket, Pedal
8	710-0347	Screw, Hex Cap, 3/8-16 x 1.75 Gr5
9	710-0514	Screw, Hex Cap, 3/8-16 x 1.0 Gr5
10	710-0607	Screw, Hex Wash Hd. Tapp, 5/16-18 x .5
11	710-0726	Screw, Hex Wash Hd. Tapp, 5/16-12 x .75
12	710-0809	Screw, Hex Wash Hd. Tapp, 1/4-20 x 1.25
13	710-1266	Screw, Hex Cap, 5/16-18 x 3.5 Gr5
14	710-1325	Screw, Hex Wash Hd. Tapp, 1/4-20 x 1.625
15	710-3073	Screw, Hex Cap, 5/16-18 x 2.25 Gr5
16	710-3119	Screw, Hex Cap Lock, 3/8-16 x .75 Gr5
17	710-04484	Screw, Hex Wash Hd. Tapp, 5/16-18 x .75
18	710-04648	Screw, Hex Cap, 7/16-14 x 8.5 Gr5
19	711-04554	Spacer, .479 x .75 x 4.97
20	711-0832	Ferrule, 3/8-24 x .375 Dia.
21	712-0346	Nut, Hex Jam Insert Lock, 1/2-20 Gr5
22	712-0431	Nut, Hex Flange Top Lock, 3/8-16 GrF
23	712-3004A	Nut, Hex Flange Lock, 5/16-18 Gr5
24	712-0290	Nut, Hex Lock, 7/16-14 GrA
25	712-3050	Nut, Lug, 7/16-14
26	712-04063	Nut, Hex Flange Insert Lock, 5/16-18 GrF
27	712-04065	Nut, Hex Flange Insert Lock, 3/8-16 GrF
28	712-0375	Nut, Hex Lock, 3/8-16
29	714-0104	Pin, Internal Cotter
30	714-0111	Pin, Cotter, 3/32 x 1/0
31	715-0143	Pin, Spirol, .25 x 1.25
32	726-0214	Cap, Push, 5/8
33	731-05846	Fan, Hydro
34	732-0209	Spring, Extension, .48 x 2.03
35	732-0335	Spring, Compression, .405 x 1.17
36	732-0716C	Spring, Extension, .59 x 4.0
37	732-0814	Spring, Extension, .56 x 5.52
38	735-0239	Pad, Foot, 4.0 in. Lg
39	735-0662	Pad, Hydro Control Pedal

Ref. No.	Part No.	Description
40	736-3027	Washer, Flat, .531 x 1.75 x .09
41	736-0227	Washer, Flat, .39 x 1.5 x .134
42	736-0290	Washer, Flat, .625 x 1.0 x .067 HT
43	736-3010	Washer, Flat, .407 x .812 x .135 HT
44	736-3039	Washer, Flat, .406 x 1.5 x .105
45	736-3050	Washer, Flat, .406 x .812 x .051
46	736-04263	Washer, Hydro Lock
47	738-0129	Bolt, Shoulder, 3/8-16: .5 x 2.0
48	738-0143	Bolt, Shoulder, .496 x .336: 3/8-16
49	738-0155	Bolt, Shoulder, .435 x .160 : 5/16-18
50	738-0347	Spacer, Shoulder, .625 ID x .169
51	741-0225	Bearing, Hex Flange
52	741-3065B	Bearing, Hex Flange, .625 ID Split
53	747-04562	Rod, Park Brake
54	747-04584A	Rod, Brake
55	747-04598	Rod, Drive Engage
56	747-04629	Bracket, Brake Pedal
57	747-04649	Rod, Hydro Dump
58	748-04155	Spacer, T-Axle
59	750-04776	Spacer, .38 x .625 x .265
60	750-0555	Spacer, .254 x .5 x .39
61	750-0566A	Spacer, .26 x .372 x 1.03
62	754-04134	V-Belt, 88.4
63	756-04209	Pulley, V Type Drive, 3.06
64	756-04274	Pulley, V Type, 4.5
65	756-0981B	Pulley, Flat Idler, 2.75
66	783-04570A	Arm, Idler
67	783-04881	Bracket, Foot Pedal Support
68	783-04981	Bracket, Park Brake
69	783-05330	Bracket, Support
70	783-05473	Bracket, Belt Keeper
71	918-04339A	Transmission, Hydro RH
72	918-04342A	Transmission, Hydro LH
73	17962	Plate, Switch
74	710-0224	Screw, Hex Wash Hd. Tapp, #10-16 x .5
75	710-0227	Screw, Hex Wash Hd. Tapp, #8-18 x .5
76	725-04039	Switch, Brake
77	725-1644	Switch, Reverse
78	726-0320	Plate, Insulator Nut
79	725-04374	Harness, Reverse Jumper
80	710-0599	Screw, Hex Wash. Hd. Tapp, 1/4-20 x .5


Engine Mounting & Connections



Engine Mounting & Connections

Ref. No.	Part No.	Description
1	683-04256	Shield, Muffler
2	710-0227	Screw, Hex Wash Hd. Tapp, #8-18 x .5
3	710-0599	Screw, Hex Wash Hd. Tapp, 1/4-20 x .5
4	710-0642	Screw, Hex Wash Hd. Tapp, 1/4-20 x .75
5	710-0654A	Screw, Hex Sems Tapp, 3/8-16 x 1.0
6	712-3005	Nut, Hex Flange Lock, 3/8-16 Gr5
7	725-0157	Tie, Cable
8	726-0154	Tie, Push Mount Cable
9	726-0205	Clamp, Hose
10	728-04000	Rivet, Pop, .188 x .3
11	736-0300	Washer, Flat, .406 x .875 x .059
12	751-0564B	Deflector, Muffler
13	751-10006	Pipe, Exhaust RH
14	751-10007	Pipe Exhaust LH
15	751-10161	Muffler, Dual Inlet
16	751-10349	Hose, Fuel ; Low Permeation, 51 inches
17	751-10353	Deflector, Muffler
18	751-3140	Valve, Oil Drain
19	751-3141	Hose, Oil Drain Extension
20	751-3142	Cap, Drain Valve
21	783-04783	Shield, Heat
22	783-04870	Bracket, Muffler LH
23	783-04872	Bracket, Muffler RH
	737-3030A	Oil, 10W30 Engine


Steering Gear Box



Steering Gear Box

Ref. No.	Part No.	Description
1	607-04243	Bracket, Steering Box Return
2	617-04036	Gear, Bevel LH
3	617-04037	Gear, Bevel RH
4	619-04153 737-0148	Housing, Steering Lower Grease, Darina
5	619-04154	Housing, Steering Upper
6	647-04083	Arm, Hydro LH
7	647-04084	Arm, Hydro RH
8	647-04085	Cam, Hydro LH
9	647-04086	Cam, Hydro RH
10	703-2441	Arm, Neutral
11	710-0599	Screw, Hex Wash Hd. Tapp, 1/4-20 x .5
12	710-04040	Screw, Shoulder, .497 x .75 : 3/8-16
13	710-0778	Screw, Hex Wash Hd. Tapp, 1/4-20 x 1.5
14	710-0809	Screw, Hex Wash Hd. Tapp, 1/4-20 x 1.25
15	711-04587	Shaft, Steering
16	712-3005	Nut, Hex Flange Lock, 3/8-16 Gr5
17	716-0102	Ring, Snap, 1.0 Dia. Shaft
18	716-0111	Ring, External Retaining, .875 Shaft
19	716-0114	Ring, Retaining, .56 Dia. Shaft
20	716-0115	Ring, Retaining, .56 Dia. Shaft
21	716-04066	Ring, Retaining, .31125 Dia. Shaft
22	717-04318	Gear, Pinion, 7T
23	717-04319	Gear, Synchro Rack
24	717-04328	Gear, Steering, 17T
25	717-04330	Gear, Steering, 26T
26	718-04229	Tube, Coupler
27	718-04269	Cam, Hydro Steering
28	721-04186	O-Ring, .625 x .07
29	732-0306A	Spring, Compression, .531 x 1.75
30	732-1162	Spring, Extension, .56 x 2.31 x .105
31	736-0369	Washer, Flat, .508 x 1.0 x .02
32	736-04237	Washer, Flat, .508 x 1.32 x .04
33	736-04257	Washer, Flat, 1.015 x 1.375 x .005
34	736-04258	Washer, Flat, 1.015 x 1.375 x .010
35	736-04259	Washer, Flat, 1.015 x 1.375 x .015
36	736-04260	Washer, Flat, 1.015 x 1.375 x .030
37	736-0864	Washer, Thrust, .375 x .812 x .06
39	741-04202	Bearing, Nylon Caster
40	741-04203	Bearing, Flange, .5 x .7
41	741-04204	Bearing, Sleeve, .437 x .3425
42	741-04206	Bearing, Sleeve, .623 x .5025 x .25
43	741-04231	Bearing, Sleeve, 1.2 x 1.0
44	741-04235	Bearing, Flange, .625 x .875
45	741-0747	Bearing, Ball, .5625 x 1.375 x .4375

46" Mowing Deck




46" Mowing Deck

Ref. No.	Part No.	Description
1	918-0660	Spindle Assembly
2	683-0254B	Bracket, Deck Hanger, LH
3	683-04278	Bracket, Idler
4	683-04335	Deck Assembly
5	710-0347	Screw, Hex Cap, 3/8-16 x 1.75 Gr5
6	710-0528	Screw, Hex Cap, 5/16-18 x 1.25 Gr5
7	710-0599	Screw, Hex Wash. Hd. Tapp, 1/4-20 x .5
8	710-1260A	Screw, Hex Wash. Hd. Tapp, 5/16-18 x .75
9	710-3015	Screw, Hex Cap, 1/4-20 x .75 Gr5
10	710-3103	Screw, Hex Cap, 5/16-18 x 2.0 Gr5
11	712-0206	Nut, Hex, 1/2-13 Gr5
12	712-04063	Nut, Hex Flange Insert Lock, 5/16-18 GrF
13	712-04065	Nut, Hex Flange Insert Lock, 3/8-16 GrF
14	712-0417A	Nut, Hex Flange, 5/8-18
15	712-0641	Nut, Hex, M16-1.5
16	712-3006	Nut, Hex, 1/4-20 Gr5
17	712-3010	Nut, Hex, 5/16-18 Gr5
18	712-3083	Nut, Hex Insert Lock, 1/2013
19	714-0111	Pin, Cotter, 3/32 x 1.0
20	714-0162	Pin, Cotter, 5/32 x 1.25
21	715-0108	Pin, Spring, 1/4 x 1.0
22	717-04074	Gear, Deck Adjust
23	721-04041	Adapter, Water Nozzle
24	726-0233	Nut, Push, .25 x .5
25	726-0269	Nut, Push On Speed, 3/8 Thrd.
26	731-3005	Roller, Front
27	732-0306A	Spring, Compression, .531 x 1.75
28	732-0594A	Spring, Extension, .91 x 7.33
29	732-0826A	Spring, Extension, .865 x 4.68
30	734-04155	Wheel, Deck Ball, 5.0
31	736-0119	Washer, Lock, 5/16
32	736-0225	Washer, Internal Tooth Lock, 5/8
33	736-0247	Washer, Flat, .406 x 1.25 x .157 HT

Ref. No.	Part No.	Description
34	736-0270	Washer, Belleville, .265 x .75 x .062
35	736-0343	Washer, Flat, .33 x 1.25 x .12
36	737-04003C	Nozzle, Deck Wash
37	738-04162a	Spacer, Shoulder, .884 x .190
38	738-04235	Shaft, 1/2 Dia x 20.8
39	738-3056	Bolt, Shoulder, .496 x 2.5:3/8-16
40	942-04124	Blade, 3 in 1 Star, 14.88
41	942-04125	Blade, 3 in 1 Star, 16.28
42	747-1116	Rod, Deck Release
43	747-1130B	Rod, Deck Front Hanger
44	750-1206	Spacer, .542 x .75 x .5
45	754-04118	V-Belt, Type A x 122.5
46	756-04129	Pulley, Idler, 4.25 Dia
47	783-0141	Skirt, Deck Center
48	783-0142	Skirt, Deck RH
49	783-05118	Bracket, Idler
50	783-05397	Bracket, Roller Height
51	783-0747B	Cover, Deck Belt LH
52	783-0805C	Cover, Deck Belt RH
53	710-0134	Screw, Carriage, 1/4-20 x .62 Gr2
54	712-3087	Nut, Wing, 1/4-20
55	731-05264	Plug, Mulching
56	756-1188	Pulley, Deck, 5.75 Dia
57	750-0952	Spacer, .792 x 1.06 x 1.8
58	741-0919	Bearing, Ball
59	738-1186	Shaft, Spindle, 6.05 Lg
60	737-3000	Fitting, Lube
61	619-0042A	Housing, Spindle
62	17983	Shield, Bearing
63	931-1032B 703-1693A 711-0792 726-0106 732-0602A	Chute Assembly, Discharge Bracket, Hinge Mounting Pin, Hinge, .25 x 6.75 Nut, Push Cap Speed, 1/4 Spring, Torsion

50" Mowing Deck




50" Mowing Deck

Ref. No.	Part No.	Description
1	16606	Bracket, Hook Retainer
2	618-04126A	Spindle Assembly
3	683-0254B	Bracket, Deck Hanger LH
4	683-04336	Deck Assembly
5	703-3279	Bracket, Chute Stop
6	703-3511A	Guard, Finger
7	710-0347	Screw, Hex Cap, 3/8-16 x 1.75 Gr5
8	710-0528	Screw, Hex Cap, 5/16-18 x 1.25 Gr5
9	710-0599	Screw, Hex Wash. Hd. Tapp, 1/4-20 x .5
10	710-0607	Screw, Hex Wash. Hd. Tapp, 5/16-18 x .5
11	710-1260A	Screw, Hex Wash. Hd. Tapp, 5/16-18 x .75
12	710-3005	Screw, Hex Cap, 3/8-16 x 1.25 Gr5
13	710-3103	Screw, Hex Cap, 5/16-18 x 2.0 Gr5
14	710-3168	Screw, Carriage, 3/8-16 x 1.0
15	710-3178	Screw, Carriage, 3/8-16 x .75
16	711-0332	Pin, Clevis, .5 x .78
17	711-1737	Pin, Roller, .5 x 10.06
18	712-0206	Nut, Hex, 1/2-13 Gr5
19	712-0229	Nut, Push, 3/8
20	712-04063	Nut, Hex Flange Insert Lock, 5/16-18 GrF
21	712-04065	Nut, Hex Flange Insert Lock, 3/8-16 GrF
22	712-0417A	Nut, Hex Flange, 5/8-18
23	712-0431	Nut, Hex Flange Lock, 3/8-16 GrF
24	712-0641	Nut, Hex, M16-1.5
25	712-3010	Nut, Hex, 5/16-18 Gr5
26	712-3083	Nut, Hex Insert Lock, 1/2013
27	714-0111	Pin, Cotter, 3/32 x 1.0
28	714-0145	Pin, Click, .092 x 1.64
29	714-0162	Pin, Cotter, 5/32 x 1.25
30	714-0470	Pin, Cotter, 1/8-1.25
31	715-0108	Pin, Spring, 1/4 x 1.0
32	717-04074	Gear, Deck Adjust
33	721-04041	Adapter, Water Nozzle
34	731-3005	Roller, Front

Ref. No.	Part No.	Description
35	732-0306A	Spring, Compression, .531 x 1.75
36	732-0459C	Spring, Extension, .94 x 6.74
37	734-04155	Wheel, Deck Ball, 5.0
38	736-0119	Washer, Lock, 5/16
39	736-0225	Washer, Internal Tooth Lock, 5/8
40	736-0300	Washer, Flat, .406 x .875 x .059
41	737-04003C	Nozzle, Deck Wash
42	738-04162A	Spacer, Shoulder, .884 x .190
43	738-04235	Shaft, .5 x 20.8
44	738-3056	Bolt, Shoulder, .496 x 2.5:3/8-16
45	942-04053A	Blade, 2 in 1 Star, 17.9
46	747-1116	Rod, Deck Release
47	747-1324	Rod, Deck Front Hanger
48	750-0151	Spacer, .55 x .75 x 1.125
49	750-1206	Spacer, .542 x .75 x .5
50	754-04077	V-Belt, B Sec., 134 in.
51	756-04129	Pulley, Idler, 4.25 Dia.
52	783-04399	Cover, Belt, LH
53	783-04400	Cover, Belt, RH
54	783-04414	Skirt, Deck Center
55	783-04415	Skirt, Deck RH
56	783-05303	Bracket, Idler,
57	783-05411	Bracket, Height Adjust
58	731-04651	Plug, Mulch
59	736-0315	Washer, Flat, .76 x 1.5 x .12
60	737-3000	Fitting, Lube
61	738-1010A	Shaft, Spindle
62	747-0919	Bearing, Ball
63	750-1000	Spacer, .80x 1.10 x 1.322
64	750-1349	Spacer, .79 x 1.84 x .55
65	756-1171	Pulley, Deck
66	631-04070A 711-04565 732-04372 783-05030	Chute Assembly, Discharge Pin, Hinge, .3125 x 14.06 Spring, Torsion, .44 x 2.1 Bracket, Chute Mounting

RH Transmission Assembly




RH Transmission Assembly

Ref. No.	Part No.	Description
1	HG-71585	Housing Assembly, Main RH
2	HG-71586	Side Assembly, RH
4	HG-70723	Block Kit - 7 Piston
5	HG-52527	Spacer, .32 x 1.005 x .179
6	HG-70331	Block Assembly, Cylinder
7	HG-9005110-5600	Plug, Straight Thread
8	HG-9004800-2506	Pin
9	HG-51190	Screw, Hex Flange
10	HG-70719	Seal, Oil
13	HG-51626	Seal, Lip
14	HG-51628	Ring, Retaining, .375 Ext.
15	HG-51625	Rod, Bypass
16	HG-51627	Ring, Retaining, .75 Int.
19	HG-51048	Swashplate, Trunnion
20	HG-51140	Seal, Lip
23	HG-52682	Arm, Control
24	736-0371	Washer, Flat, .34 x .88 x .06
25	HG-51812	Screw, 5/16-24 x 1.0
27	HG-2003014	Spring, Block
28	HG-2003017	Washer, Thrust
29	HG-51062	Shaft, Input
30	HG-50315	Bearing, Ball
31	HG-2000022	Ring, Retaining
32	HG-50951	Spacer
33	HG-51161	Seal, Lip
34	HG-50329	Ring, Retaining
35	HG-50551	Bearing, Thrust
36	HG-44371	Washer, Flat, 5/8 x 1.0 x .05
37	HG-44145	Ring, Retaining
38	HG-51767	Gear, Pinion, 12T
39	HG-52579	Shaft, Motor
40	HG-51069	Washer, Motor Shaft
41	HG-50132	Washer, HT
42	HG-51766	Gear, 10T/49T
43	HG-51043	Gear, 10T Jackshaft

Ref. No.	Part No.	Description
44	HG-51083	Pin, Jackshaft
45	HG-52531	Ring, Retaining
46	HG-52541	Gear, Bull, 52T
47	HG-52532	Washer, 1.018 x 1.57 x .105
48	HG-52542	Bearing, Sleeve
49	HG-52683	Shaft, Axle
50	HG-51517	Bearing, Sleeve
51	HG-51518	Seal, Lip
53	HG-70868R	Plate Kit, Expansion RH
57	HG-71530	Kit, Center Section RH
59	HG-71006	Kit, Bypass Arm RH
61	HG-71497	Filter Assembly
73	HG-44433	Screw, Hex
74	HG-44094	Arm, Brake
75	HG-50884	Spring, Brake
100	HG-52473	Rotor, Brake
131	HG-51616	Screw, Patch, 5/16-24 x 1
134	HG-51950	Washer, .343 x 1.5 x .062
135	HG-52401	Spring, Extension
138	HG-71510	Kit, Breather
140	HG-51946	Arm, Neutral, RH
141	HG-52432	Kit, Scissors Arm
150	917-0678	Puck, Brake
151	917-0682	Plate, Puck
153	HG-62589	Assembly, Brake Yoke
154	HG-23711	Spacer, Torsion Spring
155	941-0343	Pin, Actuating
156	HG-50919	Spring, Brake
157	HG-51146	Bolt, Special Flange
158	936-0371	Washer, Flat
159	712-0335	Nut, Castle, 5/16-24
160	914-0507	Pin, Cotter, 3/32 x .75
	HG-50928	Sealant
	HG-70853	Seal Kit

LH Transmission Assembly




LH Transmission Assembly

Ref. No.	Part No.	Description
1	HG-71030L	Housing Assembly, Main RH
2	HG-71031L	Side Assembly, RH
4	HG-70723	Block Kit - 7 Piston
5	HG-51949	Spacer, .32 x 1.005 x .179
6	HG-70331	Block Assembly, Cylinder
7	HG-9005110-5600	Plug, Straight Thread
8	HG-9004800-2506	Pin
9	HG-51190	Screw, Hex Flange
10	HG-70719	Seal, Oil
13	HG-51626	Seal, Lip
14	HG-51628	Ring, Retaining, .375 Ext.
15	HG-51625	Rod, Bypass
16	HG-51627	Ring, Retaining, .75 Int.
19	HG-51048	Swashplate, Trunnion
20	HG-51140	Seal, Lip
23	HG-52681	Arm, Control
24	736-0371	Washer, Flat, .34 x .88 x.06
25	HG-51812	Screw, 5/16-24 x 1.0
27	HG-2003014	Spring, Block
28	HG-2003017	Washer, Thrust
29	HG-51062	Shaft, Input
30	HG-50315	Bearing, Ball
31	HG-2000022	Ring, Retaining
32	HG-50951	Spacer
33	HG-51161	Seal, Lip
34	HG-50329	Ring, Retaining
35	HG-50551	Bearing, Thrust
36	HG-44371	Washer, Flat, 5/8 x 1.0 x .05
37	HG-44145	Ring, Retaining
38	HG-51767	Gear, Pinion, 12T
39	HG-52579	Shaft, Motor
40	HG-51069	Washer, Motor Shaft
41	HG-50132	Washer, HT
42	HG-51766	Gear, 10T/49T
43	HG-51043	Gear, 10T Jackshaft

Ref. No.	Part No.	Description
44	HG-51083	Pin, Jackshaft
45	HG-52531	Ring, Retaining
46	HG-52541	Gear, Bull, 52T
47	HG-52532	Washer, 1.018 x 1.57 x .105
48	HG-52542	Bearing, Sleeve
49	HG-52683	Shaft, Axle
50	HG-51517	Bearing, Sleeve
51	HG-51518	Seal, Lip
53	HG-70868L	Plate Kit, Expansion
57	HG-71529	Kit, Center Section
59	HG-71357	Kit, Bypass Arm RH
61	HG-71497	Filter Assembly
73	HG-44433	Screw, Hex
74	HG-44094	Arm, Brake
75	HG-50884	Spring, Brake
100	HG-52473	Rotor, Brake
131	HG-51616	Screw, Patch, 5/16-24 x 1
134	HG-51950	Washer, .343 x 1.5 x .062
135	HG-52401	Spring, Extension
138	HG-71510	Kit, Breather
140	HG-51945	Arm, Neutral
141	HG-52432	Kit, Scissors Arm
150	917-0678	Puck, Brake
151	917-0682	Plate, Puck
153	HG-62589	Assembly, Brake Yoke
154	HG-23711	Spacer, Torsion Spring
155	941-0343	Pin, Actuating
156	HG-50919	Spring, Brake
157	HG-51146	Bolt, Special Flange
158	936-0371	Washer, Flat
159	712-0335	Nut, Castle, 5/16-24
160	914-0507	Pin, Cotter, 3/32 x .75
	HG-50928	Sealant
	HG-70853	Seal Kit


i1046 & i1050 Crankcase; Crankshaft; and Dipstick



i1046 & i1050 Crankcase; Crankshaft; and Dipstick

Ref. No.	Part No.	Description
1	KH-32-038-01-S	Dipstick Assembly (Incl. Ref.2)
2	KH-25-153-02-S	O-Ring, Dipstick
3	KH-M-545013-S	Screw, Flnge Thrd. Frmng M5 x .8 x 13
4	KH-12-123-04	Kit, Oil Fill Tube (Incl. Ref. 5,6)
5	KH-12-153-02-S	O-ring, Upper Fill Tube
6	KH-12-153-01-S	O-ring, Lower Fill Tube
7	KH-24-126-19	Bracket, Fill Tube
8	KH-24-032-01-S	Seal, Oil
9		Crankcase - Use Short Block
10	KH-24-018-04	Retainer, Breather Reed
11	KH-12-402-02	Reed, Breather
12	KH-24-380-16-S	Pin, Locating
13	KH-24-067-16-S	Connecting Rod (Std.)
14	KH-32-874-06-S KH-32-874-08-S KH-32-874-09-S	Kit, Piston w/Ring Set (Std.) Kit, Piston w/Ring Set (.25) Kit, Piston w/Ring Set (.08)
15	KH-24-018-01-S	Retainer, Piston Pin
16	KH-24-108-11-S KH-24-108-06-S	Ring Set (Std. & .08) Ring Set (.25)
17	KH-12-422-07-S KH-12-422-08-S KH-12-422-09-S KH-12-422-10-S KH-12-422-11-S KH-12-422-12-S KH-12-422-13-S	Shim, Camshaft (White .028) Shim, Camshaft (Blue .03) Shim, Camshaft (Red .032) Shim, Camshaft (Yellow .034) Shim, Camshaft (Green .036) Shim, Camshaft (Gray .038) Shim, Camshaft (Black .04)
18	KH-32-012-01-S	Kit, Camshaft
19	KH-28-032-09-S	Seal, Governor Cross Shaft
20	KH-24-018-09-S	Retaining Ring
21	KH-M-931010-S	Washer, Flat, 9mm
22	KH-24-468-15-S	Washer, Flat, 11/32
23	KH-24-144-38-S	Shaft, Governor Cross
24	KH-32-014-04-S	Crankshaft (Incl. Ref. 25)
25	KH-52-139-09-S	Plug, Cup


i1046 & i1050 Cylinder Head/Valves/Breather



i1046 & i1050 Cylinder Head/Valves/Breather

Ref. No.	Part No.	Description
1	KH-24-755-141-S	Kit, Rocker Cover (Incl. Ref.2 & 4pc Ref. 3)
2	KH-24-153-28-S	O-Ring, Valve Cover
3	KH-M-651030-S	Screw, Flnge M6 x 1.0 x 30
4	KH-32-318-01-S	Kit, #1 Cylinder Head (Incl. 4pc Ref. 26 and KH-24-841-03-S)
5	KH-12-755-03	Kit, Retainer
6	KH-12-173-01	Cap, Valve Spring
7	KH-24-089-02	Spring, Valve
8	KH-235011-S	Retainer, Spring
9	KH-66-032-05-S	Seal, Valve Stem
10	KH-24-017-01	Valve, Intake (Std.)
11	KH-24-016-01	Valve, Exhaust (Std.)
12	KH-32-326-04-S	Kit, Breather Hose, (Incl. 1pc Ref. 13)
13	KH-25-237-14-S	Clamp, Hose
14	KH-32-081-02-S	Kit, Breather Housing (Incl. 15,16)
15	KH-M-547050-S	Nut, Lock, M5 x 0.8
16	KH-32-468-01-S	Washer, Sealing
17	KH-32-072-02-S	Stud, Breather Cover
18	KH-32-019-01-S	Kit, Tappet
19	KH-32-411-02-S	Rod, Push
20	KH-24-841-03-S	Kit, Cylinder Head Gasket (Incl. Head Mtg. Hardware and KH-24-041-49-S and KH-24-153-27-S)
21	KH-32-318-02-S	Kit, #2 Cylindre Head (Incl. 4pc Ref. 26 and KH-24-841-03-S)
22	KH-32-186-02-S	Arm, Rocker
23	KH-32-100-04-S	Nut, M10 x 0.75
24	KH-32-086-03-S	Screw, Set
25	KH-24-599-02-S	Pivot, Rocker Arm
26	KH-12-086-16	Screw, Flange, M10 x 1.5 x 90
27	KH-32-086-04-S	Screw, Flange, M6 x 1.0 x 45
28	KH-32-096-06-S	Kit, Breather Valve Cover (Incl. 1pc Ref.2)
29	KH-24-445-01	Strap, Lifting
30	KH-M-645016-S	Screw, Flnge Thrd. Frmng M6 x 1.0 x 16
31	KH-32-096-04-S	Kit, Breather Cover (Incl. Ref. 32)
32	KH-32-041-01-S	Gasket, Breather Cover
33	KH-32-050-01-S	Filter, Breather
Not Illustrated		
	KH-24-041-49-S	Gasket, Exhaust
	KH-24-153-27-S	O-Ring


i1046 & i1050 Blower Housing/Baffles



i1046 & i1050 Blower Housing/Baffles


Ref. No.	Part No.	Description
1	KH-32-027-03-S	Kit, Blower Hsng (Incl. Ref.2 & KH-41-037-10-S)
2	KH-32-096-08-S	Cover, Air Cleaner
3	KH-M-545016-S	Screw, Flng Thrd. Frmng M5 x 0.8x 16
4	KH-M-645016-S	Screw, Flng Thrd. Frmng M6 x 1.0 x 16
5	KH-32-146-05-S	Plate, Backing
6	KH-32-063-05-S	Baffle, Cyl. Barrel - #2 Side
7	KH-M-545010	Screw, Flng Thrd. Frmng M5 x 0.8x 10
8	KH-32-063-02-S	Baffle, Valley #2 Side
9	KH-32-063-03-S	Baffle, Valley #1 Side
10	KH-32-063-06-S	Baffle, Cylinder Barrel - #1 Side
11	KH-24-086-12	Screw, Tap, M6 x 1.7 x 18
		Not Illustrated
	KH-41-037-10-S	Nameplate, Service
	KH-32-113-20-S	Decal, Cub

i1046 & i1050 Oil Pan/Filter




Ref. No.	Part No.	Description
1	KH-32-199-02-S	Pan Assembly, Oil (Incl. Ref. 2-15)
2	KH-32-086-01-S	Screw, Flnge Thrd. Frmng M6 x 1.0 x 26.5
3	KH-32-393-10-S	Pump Assembly, Oil
4	KH-24-043-12	Kit, Governor Gear w/Pin (Incl. Ref. 5)
5	KH-12-380-01	Pin, Governor Regulating
6	KH-24-448-02-S	Tab, Locking
7	KH-12-144-02	Shaft, Governor Gear
8	KH-52-032-08-S	Seal, Oil (PTO End)
9	KH-32-123-01-S	Tube, Oil Feed - Filter to Pan
10	KH-32-123-03-S	Tube, Oil Feed - Pan to Filter
11	KH-24-153-01	O-Ring, Oil Pick-up
12	KH-32-029-07-S	Kit, Oil Filter Adapter
13	KH-25-139-60-S	Plug, Pipe, 1/8
14	KH-32-153-04-S	O-Ring, Oil Filter Adapter
15	KH-32-136-03-S	Nipple, Oil Filter
16	KH-25-099-27-S	Switch, Oil Pressure
17	KH-52-050-02-S	Filter, Oil
18	KH-24-086-17-S	Screw, Flange, M8 x 1.25 x 45
19	KH-25-139-57-S	Plug, Sq. Hd. Pipe, 3/8 NOT USED- Replaced by Oil Drain Valve

i1046 & i1050 Air Filter/Intake Manifold



Ref. No.	Part No.	Description
1	KH-24-164-51-S	Manifold, Intake
2	KH-24-041-52-S	Gasket, Carburetor
3	KH-24-153-27-S	O-Ring, Intake Port
4	KH-32-094-04-S	Base, Air Cleaner w/Gasket, Latch
5	KH-24-041-14	Gasket, Air Cleaner Base
6	KH-32-344-02-S	Latch, Air Cleaner Element
7	KH-32-083-03-S	Element, Air Filter
8	KH-X-25-63	Washer, Flat, 1/4
9	KH-M-651040-S	Screw, Flange, M6 x 1.0 x 40
10	KH-32-083-05-S	Pre-Cleaner, Element


i1046 & i1050 Flywheel/Electrical



i1046 & i1050 Flywheel/Electrical


Ref. No.	Part No.	Description
1	KH-32-162-03-S	Screen, Grass
2	KH-12-086-14	Screw, Flange, M10 x 1.5 x 45
3	KH-12-468-03	Washer, Flat 13/32
4	KH-20-146-02-S	Plate, Fan Mounting
5	KH-32-157-01-S	Fan
6	KH-32-025-08-S	Flywheel
7	KH-X-42-15	Key, 3/16 x 5/8
8	KH-236602-S	Connector (3 Contact)
9	KH-M-551016-S	Screw, Flange, M5 x 0.8 x 16
10	KH-41-403-09	Rectifier-Regulator
11	KH-237878	Kit, 15 Amp Stator
12	KH-235173	Clip, Cable
13	KH-M-548025-S	Screw, Thrd. Frmng M5 x 0.8x 25
14	759-3336	Plug, Spark
15	KH-24-584-45-S	Module, Ignition
16	KH-M-545020-S	Screw, Flng Thrd. Frmng M5 x 0.8x 20
		Not Illustrated
	KH-25-454-03-S	Tie, Wire
	KH-32-176-02-S	Harness, Wiring

i1046 & i1050 Fuel System/Carburetor




Ref. No.	Part No.	Description
1	KH-32-853-03-S KH-32-853-04-S	Kit, Carburetor (Incl. 2-3) Model i1046 ONLY Kit, Carburetor (Incl. 2-3) Model i1050 ONLY
2	KH- 24-041-52-S	Gasket, Carburetor
3	KH-24-041-14	Gasket, Air Cleaner Base
4	KHM-629105-S	Stud, M6 x 1.0 x 106
5	KH-M-641060-S	Nut, Flange, M6 x 1.0
6	KH-25-237-14-S	Clamp, Spring Hose 1/2
7	KH-25-111-34-S	Line, Fuel (24"- Cut to Length)
8	KH-25-431-10-S	Sleeve, Anti Abrasion
9	KH-32-326-02-S	Kit, Fuel Pump Hose w/Clamp (Incl. 10)
10	KH-25-237-01-S	Clamp, Hose
11	KH-24-086-12	Screw, Tap, M6 x 1.7 x 18
12	KH-24-393-16	Pump, Fuel
13	KH-25-050-22-S	Filter, Fuel
14	KH-47-154-01-S	Clip, Cable
		Not Illustrated
	KH-24-086-05	Screw, Throttle Stop - Model i1046 ONLY
	KH-X-25-63	Washer, Flat, 1/4
	KH-24-757-36-S	Service Kit, Choke Repair
	KH-24-757-38-S	Service Kit, Gasket
	KH-24-757-44-S	Kit, Float Repair
	KH-24-757-45-S	Kit, Solenoid Valve Repair
	KH-24-757-46-S	Kit, Carburetor Overhaul Repair

i1046 & i1050 Starter Motor



Ref. No.	Part No.	Description
1	KH-M-839080	Screw, Flange, M8 x 1.25 x 80
2	KH-32-098-01-S	Starter Assembly
3	KH-12-755-39-S	Kit, Drive
4	KH-12-755-38-S	Kit, Drive Parts (Incl. Ref. 5)
5	KH-32-141-01-S	Ring, Retaining Ring
6	KH-32-211-01-S	Bolt, Thru
7	KH-12-243-04-S	Commutator, End Cap


i1046 & i1050 Engine Controls



i1046 & i1050 Engine Controls

Ref. No.	Part No.	Description
1	KH-24-211-03-S	Bolt, Carriage, M6 X 1.0 X 25
2	KH-24-090-33-S	Lever, Governor
3	KH-M-641060-S	Nut, Flange, M6 x 1.0
4	KH-24-089-01	Spring, Linkage
5	KH-25-158-08	Bushing, Linkage Retainer
6	KH-24-079-04	Linkage, Throttle
7	KH-25-158-11	Bushing, Throttle Linkage
8	KH-M-545016-S	Screw, Flng. Thrd. Frmng, M5 x 0.8 x 16
9	KH-M-547050-S	Nut, Lock, M5 x 0.8
10	KH-24-089-03	Spring, Choke Return
11	KH24-126-161-S	Bracket, Control
12	KH-M-645016-S	Screw, Flng. Thrd. Frmng M6 x 1.0 x 16
13	KH-47-237-02	Clamp, Dual Conduit
14	KH-24-086-43-S	Screw, Torx Hd. Ctsk, M5 x 0.8 x 16
15	KH-24-079-22-S	Linkage, Choke
16	KH-24-112-27-S	Spacer, Control Assembly
17	KH-24-090-47-S	Lever, Throttle Actuator
18	KH-24-090-13	Lever, Throttle Control
19	KH-24-468-01	Washer, Flat, 5.5mm
20	KH-M-545020-S	Screw, Flng. Thrd. Frmng, M5 x 0.8 x 20
21	KH-41-468-03	Washer, Spring, 1/4
22	KH-24-090-05	Lever, Choke
23	KH-M-403025	Screw, Hex Cap, M4 x 0.7 x 25
24	KH-M-446030-S	Nut, M4 x 0.7
25	KH-24-468-20-S	Washer, Flat, 5mm
26	KH-24-089-55-S	Spring, Governor
27	KH-24-089-18 KH-24-089-25-S	Spring, Governor, Model i1046 ONLY Spring, Governor, Model i1050 ONLY

Model i1050 Labels



For Headlight
777X42426
 Right Lens

777X42427
 Left Lens

777S32771

777D10608
 Centered Over **777S32771**

777122702
 On Dash Cluster

777122679
 Top Of Engine

SEAL OIL

(QTY) 2 777122708
 Aside Trans.
 Release Rods

777S32815
 On Hitch Plate

WARNING
 NO OPEN FLAMES OR SPARKS
 AND MAKE WIDE TURNS
 TO AVOID JACK-KNIFING

(QTY) 2 777D10609
 Front Of Deck

50 CUT

777S30015

WARNING
 DANGER

777S30503

DANGER
 NEVER OPERATE THIS MOWER WITH OIL LEAKING FROM THE ENGINE OIL PAN.

(QTY) 2 777D10624
 Near Each Nozzle

SMART-JET DECK WASH SYSTEM

777D10501

Cub Cadet

Gear Top

(QTY) 2 777S32807
 On Both
 Gear Tops

WARNING
 SHIELD EYES AND WEAR PROTECTIVE GLASSES

777122707
 Right Of
 Gas Gauge

F E

777D10491
 On Rear Fender

Cub Cadet

777D10496
 In Molded On Hood

Cub Cadet

777D10494
 In Molded On Hood

Cub Cadet

(QTY) 2 777D10623
 On Both Sides Place
 As Shown

Time Saver i1050

UNDER HOOD

777X42474

ITEM	DESCRIPTION	QTY	UNIT
777X42474	UNDER HOOD LABEL	1	EA
777X42475	UNDER HOOD LABEL	1	EA
777X42476	UNDER HOOD LABEL	1	EA
777X42477	UNDER HOOD LABEL	1	EA
777X42478	UNDER HOOD LABEL	1	EA
777X42479	UNDER HOOD LABEL	1	EA
777X42480	UNDER HOOD LABEL	1	EA
777X42481	UNDER HOOD LABEL	1	EA
777X42482	UNDER HOOD LABEL	1	EA
777X42483	UNDER HOOD LABEL	1	EA
777X42484	UNDER HOOD LABEL	1	EA
777X42485	UNDER HOOD LABEL	1	EA
777X42486	UNDER HOOD LABEL	1	EA
777X42487	UNDER HOOD LABEL	1	EA
777X42488	UNDER HOOD LABEL	1	EA
777X42489	UNDER HOOD LABEL	1	EA
777X42490	UNDER HOOD LABEL	1	EA