

Cub Cadet[®]


ILLUSTRATED PARTS MANUAL




54" RZT Series Tractor

CUB CADET LLC, P.O. BOX 361131 CLEVELAND, OHIO 44136-0019

Frame & Drive Idler Assembly




Ref.	Part Number	Description
1.	603-04680-4021	Frame Assembly
2.	703-05829-0637	Drive Idler Arm
3.	710-0520	Hex Screw, $\frac{3}{8}$ -16 x 1.5
4.	710-3005	Hex Screw, $\frac{3}{8}$ -16 x 1.25
5.	712-04065	Flange Nut, $\frac{3}{8}$ -16
6.	732-0626	Extension Spring, .75 x 5.06
7.	936-0300	Flat Washer, .408 x .875 x .059
8.	738-04058	Shoulder Spacer, .39 x 1.0 x .7
9.	738-04162A	Shoulder Spacer, .884 x .19
10.	756-04129	Idler Pulley, 4.25 Dia.



Ref.	Part Number	Description
1.	710-0599	Hex Screw, 1/4-20 x .5
2.	710-3015	Hex Screw, 1/4-20 x .75
3.	712-0271	Hex Nut, 1/4-20
4.	925-04022B	Hour Meter
5.	925-04165	Double Pole — Neutral Switch
6.	925-04174	PTO Switch
7.	925-04228	Ignition Switch
8.	725-04363	Interlock Switch
9.	725-04439	Solenoid

Ref.	Part Number	Description
10.	925-1745A	Key
11.	925-1707D	Battery
12.	738-04237A	Shoulder Screw, #10-32 x .500
13.	726-0470	Cable Tie
14.	703-05894-0637	Battery Hold-down
15.	731-0511-12	Trim Strip
16.	710-0653	Hex Screw, 1/4-20 x .375
17.	925-04040	Seat Switch

Operator's Platform




Ref	Part Number	Description
1	603-04564-4021	Console Mount Bracket
2	603-04663-4021	Seat Frame
3	735-04082	Foot Pad
4	703-05373B-4021	Foot Rest
5	736-0148	Lock Washer, 3/8
6	703-06451-4021	Console Mount Bracket
7	703-06623-0637	Fuel Tank Support Bracket
8	710-04484	Hex Washer Screw, 5/16-18 x .750
9	757-04098	High-Back Seat
10	710-0604A	Hex Washer Screw, 5/16-18 x .825
11	710-0778	Hex Washer Screw, 1/4-20 x 1.500
12	710-0895	Hex Washer Screw, 1/4-15 x .750
13	710-3008	Hex Screw, 5/16-18 x .75

Ref	Part Number	Description
14	912-0298	Jam Nut, 1/4-20
15	712-04063	Flange Lock Nut, 5/16-18
16	712-04092	U-Type Nut, 1/4-20
17	726-3046	Ratchet Clip, .250
18	731-06233	RH Console
19	731-06263	LH Console
20	710-1238	Hex Washer Screw, 5/16-18 x .875 *
21	936-3008	Flat Washer, .344 x .750 x .120 *
22	951-10589	Carbon Canister *
23	951-10590	Canister Filter Vent *
24	951-10610	Canister Adapter Bracket *
25	751-10750-28	Low Permeation Fuel Hose *

* — California Models Only


Rear Drive & Wheels



Ref.	Part Number	Description
1	918-04464	Transmission Assembly (RH)
2	918-04465	Transmission Assembly (LH)
3	618-04466	Breather
4	931-04223	Expansion Tank Assembly
5	N/A	Wheel Assembly, 20 x 10 x 8
—	634-0246A-0499	Rim Assembly, 8.0 x 6.19 x 4
—	734-1873-0901	Tire, 20 x 10 x 8
—	934-0255	Air Valve
6	703-05938A-0637	Expansion Tank Bracket
7	703-05940-0637	Transmission Brace (LH)
8	703-05941-0637	Transmission Brace (RH)
9	703-05989-0637	Transmission Spacer
10	710-0176	Hex Screw, $\frac{5}{16}$ -18 x 2.75
11	710-0189	Hex Screw, $\frac{5}{16}$ -18 x 3.00
12	710-0599	Screw, $\frac{1}{4}$ -20 x .500
13	710-0788	Screw, $\frac{1}{4}$ -20 x 1.000

Ref.	Part Number	Description
14	711-1530	Ferrule, .325 x .312
15	712-04063	Flange Lock Nut, $\frac{5}{16}$ -18
16	712-04065	Flange Lock Nut, $\frac{3}{8}$ -16
17	712-04092	Speed Nut, $\frac{1}{4}$ -20
18	712-3050	Lug Nut, $\frac{7}{16}$ -14
19	914-0104	Cotter Pin, .072 x 1.13
20	726-04059	Hose Clamp, .750
21	731-05785	Cap, $\frac{1}{2}$ x .870
22	732-0335	Compression Spring, .405 x 1.17
23	732-04434	Extension Spring, .545 x 4.555
24	736-04267	Flat Washer, .35 x 1.0 x .2
25	738-04251	Rod, .337 x 14.75
26	747-04636	Bypass Rod
27	750-04759A	Tube, $\frac{7}{16}$ x $\frac{3}{4}$ x 11.3
28	751-10511	Straight Fitting, $\frac{9}{16}$ x $\frac{1}{2}$
29	954-04043A	V-Type Belt


Kawasaki FH721V-BW04 Engine Connection



Kawasaki FH721V-BW04 Engine Connection

Ref.	Part Number	Description
1	703-05441A	Muffler Mounting Bracket
2	710-0227	Hex Washer Head Screw, #8-18 x .5
3	710-04379A	Hex Cap Lock Screw, 7/16-20 x 3.5
4	710-1017	AB Screw, 1/4-14 x .625
5	710-0599	Hex Washer Head Screw, 1/4-20 x .5
6	710-1315	Hex Washer Hd. Screw, 3/8-16 x 1.25
7	710-3008	Hex Cap Screw, 5/16-18 x .75
8	710-3217	Truss Hd. Mach. Screw, #8-32 x .375
9	712-0142	Hex Nut, #8-32
10	912-0429	Hex Insert Lock Nut, 5/16-18
11	912-3005	Hex Jam Nut, 3/8-16
12	917-1774C	Electric PTO Clutch Assembly
13	726-0205	Hose Clamp
14	731-04914	Throttle Control Knob
15	936-0171	Lock Washer, 7/16
16	936-0300	Flat Washer, .406 x .875 x .059
17	736-0277	Flat Washer, 1.031 x 1.62 x .095
18	737-04138	Hex Fitting
19	746-04066	Throttle Cable, 34.25 LG
20	746-04214	Choke Cable, 61 LG
21	751-10349-28	Fuel Line Hose
22	751-0564B	Muffler Deflector
23	751-0616B	Muffler
24	N/A	Fuel Tank Assembly
—	935-0149	Fuel Tank Bushing
—	751-10442	Fuel Pick-Up Bushing
—	751-10692	Fuel Tank
—	751-10703A	Fuel Cap
25	751-10355	Exhaust Pipe, RH
26	751-10356	Exhaust Pipe, LH
27	951-10517	Oil Drain
28	751-3141-14	Oil Drain Extension Hose
29	758-04376	Drive Pulley
30	712-0271	Sems Nut, 1/4-20
31	926-0154	Push Mount Cable Tie
32	726-0272	Clamp
NS	726-0197	Clutch Cable Tie — Not Shown

Kawasaki FR691-S04/S05 Engine Connection




Kawasaki FR691-S04/S05 Engine Connection

Ref.	Part Number	Description
1	703-05441A	Muffler Mounting Bracket
2	710-0227	Hex Washer Head Screw, #8-18 x .5
3	710-04379A	Hex Cap Lock Screw, 7/16-20 x 3.5
4	710-0599	Hex Washer Head Screw, 1/4-20 x .5
5	710-1017	AB Screw, 1/4-14 x .625
6	710-1315	Hex Washer Hd. Screw, 3/8-16 x 1.25
7	710-3008	Hex Cap Screw, 5/16-18 x .75
8	710-3217	Truss Hd. Mach. Screw, #8-32 x .375
9	712-0142	Hex Nut, #8-32
10	712-0271	Sems Nut, 1/4-20
11	912-0429	Hex Lock Nut, 5/16-18
12	912-3005	Flange Lock Nut, 3/8-16
13	917-1774C	Electric PTO Clutch
14	926-0154	Cable Tie
15	726-0197	Cable Tie
16	726-0205	Hose Clamp
17	726-0272	Clamp
18	731-04914	Throttle Control Knob
19	736-0148	Lock Washer, 3/8
20	936-0171	Lock Washer, 7/16
21	736-0277	Flat Washer, 1.031 x 1.620 x .095

Ref.	Part Number	Description
22	936-0300	Flat Washer, .406 x .875 x .059
23	737-04138	Hex Fitting
24	746-04214	Choke Cable
25	946-04581	Throttle Cable
26	751-0564B	Muffler Deflector
27	751-0616B	Dual Inlet Muffler
28	751-10291	Oil Drain Hose
29	751-10349-28	Fuel Hose
30	751-10770	RH Exhaust Pipe
31	751-10771	LH Exhaust Pipe
32	756-04376	Electric PTO Engine Pulley
33	N/A	Fuel Tank Assembly (49-St.)
—	935-0149	Fuel Tank Bushing
—	751-10442	Fuel Pick-Up Bushing
—	751-10692	Fuel Tank
—	751-10703A	Fuel Cap
34	651-04174	Fuel Tank Assembly (Calif. Models)
—	935-0149	Fuel Tank Bushing
—	735-04081	Rubber Grommet
—	751-10441	Rollover Valve Grommet
—	751-10442	Fuel Pick-Up Fitting

Deck Lift & Controls




Deck Lift & Controls

Ref.	Part Number	Description	Ref.	Part Number	Description
1.	603-04160B	Deck Lift Shaft Assembly	28.	723-04035	Rod End
2.	603-04322-0637	Lapbar Lever RH	29.	727-04141	Damper Cylinder
3.	603-04324-0637	Lapbar Lever LH	30.	731-04735	Handle Grip
4.	947-04065	Brake Rod	31.	731-05732	Spacer, .62 x 1.0
5.	647-04099A	Control Shaft	32.	731-05882	Hand Grip
6.	703-05387B	Lapbar Pivot Bracket	33.	932-0334	Compression Spring
7.	703-05396A-0637	Brake Handle	34.	732-0874	Torsion Spring
8.	703-05414A-4021	Front Deck Hanger Bracket	35.	736-0270	Bell Washer, .265 x .75 x .062
9.	703-05793A-4021	Deck Lift Arm	36.	936-0272	Flat Washer, .51 x 1.0 x .06
10.	703-06096	Switch Actuator Bracket	37.	936-0275	Flat Washer, .344 x .688 x .065
11.	703-06169-0637	Lift Link Plate	38.	736-3019	Flat Washer, .531 x 1.062 x .134
12.	710-0347	Hex Screw, 3/8-16 x 1.75	39.	738-0143	Shoulder Screw, .498 x .340 x 3/8-16
13.	710-0433	Hex Lock Screw, 1/4-20 x .62	40.	938-0296	Shoulder Screw, .437 x .268 x 5/16-18
14.	710-3005	Hex Cap Screw, 3/8-16 x 1.25	41.	938-0507B	Shoulder Screw, .5 x .434 x 3/8-16
15.	710-3008	Hex Cap Screw, 5/16-18 x .75	42.	938-0572	Shoulder Screw, .374 x 1.16 x 1/4-20
16.	710-3180	Hex Cap Screw, 5/16-18 x 1.75	43.	938-0974	Shoulder Screw, .375 x .38 x 1/4-20
17.	911-0332	Clevis Pin, .50 x .78	44.	941-0225	Hex Flange Bearing
18.	912-0206	Hex Nut, 1/2-13	45.	741-3074	Flange Bearing, .626 x .938 x .344
19.	712-04063	Hex Flange Insert Lock Nut, 5/16-18	46.	747-04401A	Deck Front Hanger Rod
20.	712-04064	Hex Flange Insert Lock Nut, 1/4-20	47.	747-04637	Deck Lift Handle Rod
21.	712-04065	Hex Flange Insert Lock Nut, 3/8-16	48.	747-05057	Lapbar Control Rod
22.	912-0431	Hex Flange Lock Nut, 3/8-16	49.	948-0227A	Hex Flange Bearing
23.	912-3001	Jam Nut, 3/8-24	50.	748-04169-0637	Control Hub
24.	914-0104	Cotter Pin	51.	750-04676	Spacer, .385 x .630 x .75
25.	914-04023	Cotter Pin	52.	750-04776	Spacer, .380 x .625 x .265
26.	716-0106	E-Ring, .625 Dia.	53.	732-04420	Torsion Spring
27.	720-0311	Handle Grip			

Ref.	Part Number	Description
1.	96606	Retainer Bracket
2.	903-04603-4021	Deck Housing
3.	603-04386A-4021	Idler Assembly
4.	918-04671B	Spindle Assembly
5.	631-04070A	Discharge Chute Assembly
6.	638-04012A	Shoulder Bolt Assembly
7.	683-0254B-4021	Deck Hanger Bracket
8.	703-2093-0637	Rear Inner Baffle
9.	703-3279-4021	Stop Bracket
10.	703-3511A-0637	Finger Guard
11.	631-04070A	Chute Deflector
12.	710-0347	Hex Cap Screw, 3/8-16 x 1.75
13.	710-0521	Hex Cap Screw, 3/8-16 x 3.0
14.	710-0528	Hex Cap Screw, 5/16-18 x 1.25
15.	710-0599	Hex Washer Screw, 1/4-20 x .5
16.	710-04484	Hex Washer Screw, 5/16-18 x .750
17.	710-0623	Hex Washer Screw, 3/8-16 x .75
18.	710-0650	Hex Washer Screw, 5/16-18 x .875
19.	703-05970-0637	Frame Support Bracket
20.	710-3168	Carriage Screw, 3/8-16 x 1.0
21.	710-3178	Carriage Screw, 3/8-16 x .75
22.	711-1737	Roller Pin, .5 x 10.06
23.	712-0290	Hex Lock Nut, 7/16-14
24.	712-04065	Hex Insert Flange Lock Nut, 3/8-16
25.	712-0417A	Hex Flange Nut, 5/8-18
26.	912-0431	Hex Flange Lock Nut, 3/8-16
27.	912-0641	Hex Nut, M16-1.5
28.	914-0111	Cotter Pin, 3/32 x 1.0
29.	714-0162	Cotter Pin, 5/32 x 1.25
30.	914-0470	Cotter Pin, 1/8 x 1.25
31.	917-04074	Deck Adjustment Gear
32.	921-04041	Water Nozzle Adapter
33.	731-05825	Deck Roller, 7.895
34.	731-05679	Front Roller


Ref.	Part Number	Description
35.	932-0306A	Compression Spring
36.	732-04609	Extension Spring, .94 x .04609
37.	734-04155	Deck Ball Wheel, 5.0
38.	936-0119	Lock Washer, 5/16
39.	936-0275	Flat Washer, .344 x .688 x .065
40.	936-0406	Flat Washer, .442 x 1.39 x .06
41.	736-0407	Bell Washer, .45 x 1.0 x .062
42.	936-0760	Lock Washer
43.	736-3010	Flat Washer, .407 x .812 x .135
44.	736-3072	Flat Washer, .38 x .93 x .110
45.	737-04003D	Deck Wash Nozzle
46.	738-04260	Shaft, .75 x 26.893
47.	938-3056	Shoulder Screw, .5 x 2.5 x 3/8-16
48.	942-0677B	Blade, 18.5
49.	747-1116	Deck Hanger Rod
50.	950-0151	Spacer, .55 x .75 x 1.125
51.	950-0212	Spacer, .82 x 1.0 x .53
52.	750-04597	Spacer, .38 x .9 x 1.313
53.	954-04138A	V-Belt
54.	756-04129	Idler Pulley, 4.25 Dia
55.	783-04690B-0637	Deck Skirt
56.	783-04726-0637	Stationary Idler Bracket
57.	783-1470A-4021	Belt Cover, RH
58.	783-1471-4021	Belt Cover, LH
59.	783-05034A-0637	Chute Mounting Bracket
60.	732-04372	Torsion Spring
61.	711-04565	Hinge Pin
62.	738-1197	Spindle Shaft, 6.95
63.	941-0919	Ball Bearing
64.	748-0160A	Spacer, .79 x 1.25 x .175
65.	750-1000	Spacer, .80 x 1.10 x 1.32
66.	750-1349A	Spacer, .79 x 1.82 x .55
67.	756-04216	V-Type Pulley, 5.39

Front Axle



Ref.	Part Number	Description
1.	603-04370-4021	Castor Wheel Bracket
2.	603-04385A-4021	Front Pivot Axle
3.	634-04321A	Wheel Assembly, 13 x 5-6
—	734-04255A	Tire, 13 x 5-6
4.	710-04186	Hex Lock Screw, 1/2-13 x 1.25
5.	710-04652	Hex Cap Screw, 1/2-20 x 7.25
6.	710-0514	Hex Cap Screw, 3/8-16 x 1.0
7.	911-04228	Axle Shaft
8.	912-3058	Hex Insert Lock Nut, 1/2-13
9.	731-05500	Flange Bearing, 1.0 x 1.246
10.	936-0169	Lock Washer, 3/8
11.	936-0227	Flat Washer, .39 x 1.5 x .134
12.	736-0250	Flat Washer, 1.0 x 1.75 x .10
13.	937-3000	Lube Fitting, 3/16 Drive
14.	750-04775A	Spacer, .51 x .75 x 5.825
15.	750-04792	Hub, .76 x 1.23 x .92


Seat Adjustment



Ref.	Part Number	Description
1.	703-06941-4021	Seat Bracket
2.	710-04482	Hex Flange Bolt, $\frac{3}{8}$ -16 x .875
3.	710-04484	Hex Washer Screw, $\frac{5}{16}$ -18 x .750
4.	712-04063	Flange Lock Nut, $\frac{5}{16}$ -18
5.	732-04035	Compression Spring
6.	732-04563	Compression Spring
7.	736-0258	Flat Washer, .385 x 1.0 x .135
8.	938-0296	Shoulder Screw, .437 x .268 x $\frac{5}{16}$ -18
9.	783-06049-4021	Seat Mount Bracket
10.	783-06050	Seat Adjustment Lever

Kawasaki FR691V-AS04 Cylinder/Crankcase

E0110-A630A




Kawasaki FR691V-AS04 Cylinder/Crankcase

Ref.	Part Number	Description
11004	KM-11004-7026	Head Gasket
11008	KM-11008-7039	Complete Cylinder Head, #1
11008A	KM-11008-7040	Complete Cylinder Head, #2
11022	KM-11022-7019	Rocker Case, #1
11022A	KM-11022-7020	Rocker Case, #2
11061	KM-11061-7083	Rocker Case Gasket
11061A	KM-11061-7084	Breather Gasket
13272	KM-13272-7004	Breather Plate
14091	KM-14091-7064	Breather Cover
16126	KM-16126-7020	Breather Valve
32154	KM-32154-7019	Pipe
32155	KM-32155-7003	Breather Pipe
49015	KM-49015-7079	Crankcase Cover
49120	KM-49120-7122	Complete Crankcase
59071	KM-59071-2079	Joint
92043	KM-92043-1263	Pin
92049	KM-92049-7001	Oil Seal, RVC 26 x 11 x 10.2
92049A	KM-92049-7005	Oil Seal, SO 8 x 14 x 5 HS
92049B	KM-92049-7010	Oil Seal, SD 35 x 48 x 8 RHS
92049C	KM-92049-7028	Oil Seal, 38 x 62 x 8 MTCLV
92066	KM-92066-7023	Plug
92066A	KM-92066-7026	Plug
92153	KM-92153-7043	Bolt, 6 x 12
92153A	KM-92153-7054	Bolt, 8 x 50
130	KM-130AA0625	Flanged Bolt, 6 x 25
130A	KM-130CA1050	Flanged Bolt, 10 x 50
130B	KM-130CA1065	Flanged Bolt, 10 x 65
172	KM-172BA0818	Stud Bolt, 8 x 18
214	KM-214AA0408	Pan Screw +-, 4 x 8
670	KM-670B2011	O-Ring, 11mm

Kawasaki FR691V-AS04 Piston/Crankshaft


E0120-A398A



Ref.	Part Number	Description
13001	KM-13001-7027	Engine Piston
13002	KM-13002-7006	Piston Pin
13008	KM-13008-7005	Piston Ring Set
13025	KM-13025-7009	Piston Ring Set, L ,0.5
13029	KM-13029-7010	Engine Piston, L, 0.5
13031	KM-13031-7084	Complete Crankshaft
13251	KM-13251-7025	Connecting Rod Assembly
92033	KM-92033-7016	Snap Ring
92151	KM-92151-7017	Bolt, 6 X 35

Kawasaki FR691V-AS04 Valve/Camshaft

E0130-A176A




Ref.	Part Number	Description
11055	KM-11055-7009	Bracket
12004	KM-12004-7008	Intake Valve
12005	KM-12005-7009	Exhaust Valve
12009	KM-12009-7001	Valvespring Retainer
12011	KM-12011-2056	Collet
12016	KM-12016-2066	Rocker Arm
12032	KM-12032-7001	Tappet
13070	KM-13070-7017	Governor Guide
13116	KM-13116-7007	Push Rod
13271	KM-13271-7007	Plate
13271A	KM-13271-7021	Governor Plate
42036	KM-42036-7010	Sleeve

Ref.	Part Number	Description
49078	KM-49078-7002	Engine Valve Spring, IN
49118	KM-49118-7022	Complete Camshaft
92033	KM-92033-7001	Snap Ring
92140	KM-92140-7005	Ball
92145	KM-92145-7001	Spring
92152	KM-92152-7012	Collar
92153	KM-92153-7100	Bolt, 6 X 29.5
92200	KM-92200-2151	Washer, 8.1 X 18 X 0.5
92200A	KM-92200-7009	Washer, 16 X 42 X 0.91
92200B	KM-92200-7048	Washer, 16.3 X 30 X 2.28
130	KM-130AA0814	Flanged Bolt, 8 X 14
312	KM-312AA0600	Hex Nut, 6mm

Kawasaki FR691V-AS04 Lubrication Equipment


E0140-A447A



Ref.	Part Number	Description
13272	KM-13272-7011	Rotor Plate
14075	KM-14075-7013	Oil Gauge Cap Assembly
16154	KM-16154-7010	Outer Pump Rotor
16154A	KM-16154-7011	Inner Pump Rotor
49065	KM-49065-7006	Oil Filter
49065A	KM-49065-7007	Oil Filter
59231	KM-59231-7016	Filler
92066	KM-92066-7003	Plug
92066A	KM-92066-7028	Plug
92140	KM-92140-7003	Ball
92145	KM-92145-7002	Spring
92153	KM-92153-7008	Bolt
92153A	KM-92153-7043	Bolt, 6 X 12
555	KM-555A0420	Spring Pin, 4 X 20
670	KM-670D2016	O-Ring, 16mm

Kawasaki FR691V-AS04 Cooling Equipment


E0150-A873A



Ref.	Part Number	Description
13070	KM-13070-7019	Cooling Air Guide
13272	KM-13272-7006	Fan Plate
14037	KM-14037-70089H	Screen
23062	KM-23062-7005	Complete Bracket
49089	KM-49089-7079	Engine Shroud
49089A	KM-49089-7080	Engine Shroud
59041	KM-59041-7014	Fan
59066	KM-59066-7046	Fan Housing
92009	KM-92009-2303	Screw
92026	KM-92026-7007	Spacer
92151	KM-92151-7012	Bolt, 6 X 12
92153	KM-92153-7007	Bolt
92153A	KM-92153-7043	Bolt, 6 X 12

Kawasaki FR691V-AS04 Cooling Equipment

E0160-B284A





Ref.	Part Number	Description
13272	KM-13272-7012	Plate
21066	KM-21066-7017	Voltage Regulator
21171	KM-21171-7041	Ignition Coil Assembly
21193	KM-21193-7038	Flywheel Assembly
26011	KM-26011-7025	Lead Wire, L = 95
26031	KM-26031-7040	Harness
26031A	KM-26031-7041	Harness
26031B	KM-26031-7044	Harness
59031	KM-59031-7017	Charging Coil
92009	KM-92009-2303	Screw

Ref.	Part Number	Description
92009A	KM-92009-2308	Screw
92066	KM-92066-7026	Plug
92070	759-3339	Spark Plug
92072	KM-92072-7003	Band
92151	KM-92151-2097	Bolt, 12 X 30
92171	KM-92171-7008	Clamp
92172	KM-92172-7018	Screw, 5 X 20
92200	KM-92200-7002	Washer
130	KM-130AA0620	Flanged Bolt, 6 X 20
510	KM-510A5100	Woodruff Key

Kawasaki FR691V-AS04 Control Equipment

E0170-A652A




Ref.	Part Number	Description
13107	KM-13107-7047	Shaft
13271	KM-13271-7038	Plate
16171	KM-16171-7022	Link
39129	KM-39129-7028	Governor Spring
49103	KM-49103-7014	Governor Arm
49103A	KM-49103-7015	Governor Arm
49113	KM-49113-7050	Complete Control Panel
92145	KM-92145-7057	Spring
92145A	KM-92145-7058	Spring
92150	KM-92150-2182	Bolt, 5 X 18

Ref.	Part Number	Description
92153	KM-92153-0009	Bolt, 6 X 12
92153A	KM-92153-7033	Bolt, 6 X 35
92153B	KM-92153-7043	Bolt, 6 X 12
92170	KM-92170-7001	Clamp
92172	KM-92172-7035	Screw, 5 X 30
214	KM-214AA0408	Pan Screw +-, 4 X 8
311	KM-311AA0600	Hex Nut, 6mm
312	KM-312AA0500	Hex Nut, 5mm
411	KM-411AA0600	Plain Washer, 6mm

Kawasaki FR691V-AS04 Carburetor

E0180-A778A




Ref.	Part Number	Description
11061	KM-11061-7009	Chamber Gasket
11061A	KM-11061-7010	Screw Gasket
11061B	KM-11061-7085	Manifold Gasket
11061C	KM-11061-7087	Insulator Gasket
11061D	KM-11061-7088	Insulator/Manifold Gasket
13107	KM-13107-7018	Shaft
15004	KM-15004-7063	Carburetor Assembly
16014	KM-16014-7010	Pilot Air Screw
16020	KM-16020-7003	Float Chamber
16025	KM-16025-7017	Throttle Valve
16030	KM-16030-7003	Float Valve
16031	KM-16031-7002	Float
16041	KM-16041-7050	Choke Carburetor Shaft
16041A	KM-16041-7051	Throttle Carburetor Shaft
16073	KM-16073-7013	Insulator
16186	KM-16186-7006	Choke Valve Assembly

Ref.	Part Number	Description
21188	KM-21188-7002	Solenoid
39074	KM-39074-7001	Throttle Lever Assembly
49121	KM-49121-7018	Main Nozzle
59076	KM-59076-7019	Intake Manifold
92009	KM-92009-2083	Screw
92009A	KM-92009-2349	Screw
92009B	KM-92009-2402	Screw
92063	KM-92063-7141	Main Jet, #122
92063A	KM-92063-7142	Main Jet, #124
92063B	KM-92063-7149	Main Jet, #120
92081	KM-92081-2234	Spring
92093	KM-92093-2100	Seal
92093A	KM-92093-7003	Seal
92145	KM-92145-2122	Spring
130	KM-130AA0630	Flanged Bolt, 6 X 30
172	KM-172BA06115	Stud Bolt, 6 X 115

Kawasaki FR691V-AS04 Air Filter/Muffler


E0190-B079A



Ref.	Part Number	Description
11011	KM-11011-7054	Air Filter Case
11013	KM-11013-7047	Air Filter Element
11060	KM-11060-7016	Muffler Gasket
11061	KM-11061-7086	Carburetor/Pipe Intake Gasket
16060	KM-16060-7035	Intake Pipe
42036	KM-42036-7017	Breather Sleeve
92009	KM-92009-2303	Screw
92015	KM-92015-1367	Nut
92171	KM-92171-7007	Clamp
92173	KM-92173-7003	Clamp
92192	KM-92192-7146	Tube, 12.6 X 18.6 X 118
92192A	KM-92192-7151	Air Filter Tube
92210	KM-92210-7027	Nut, M8
461	KM-461DA0800	Spring Washer, 8mm

Kawasaki FR691V-AS04 Fuel Tank/Fuel Valve


E0200-A679A



Ref.	Part Number	Description
42036	KM-42036-7015	Sleeve
49019	KM-49019-7005	Fuel Filter
49040	KM-49040-7008	Fuel Pump
92009	KM-92009-2303	Screw
92170	KM-92170-2009	Clamp
92171	KM-92171-7008	Clamp
92192	KM-92192-7145	Tube, 6.35 X 12.7 X 185
92192A	KM-92192-7148	Tube, 6.4 X 12.7 X 150
92192B	KM-92192-7150	Tube, 6.35 X 12.7 X 390

Kawasaki FR691V-AS04 Carburetor

E0210-A452A



Ref.	Part Number	Description
16146	KM-16146-7027	Cover Assembly
16146A	KM-16146-7028	Cover Assembly
21080	KM-21080-7006	Armature
21163	KM-21163-7024	Electric Starter
27012	KM-27012-7004	Hook
32085	KM-32085-7004	Stopper
59051	KM-59051-7034	Spur Gear
92093	KM-92093-7007	Seal
92145	KM-92145-7060	Spring
92154	KM-92154-7001	Bolt
92210	KM-92210-7017	Nut
92210A	KM-92210-7036	Nut
130	KM-130AA0840	Flanged Bolt, 8 X 40

Kawasaki FR691V-AS04 Engine Labels

56033




56070



Ref.	Part Number	Description
56033	KM-56033-7001	Manual Label
56070	KM-56070-7001	Warning Label

Kawasaki FR691V-AS05 Piston/Crankshaft


E0120-A398A



Ref.	Part Number	Description
13001	KM-13001-7027	Engine Piston
13002	KM-13002-7006	Piston Pin
13008	KM-13008-7005	Piston Ring Set
13025	KM-13025-7009	Piston Ring Set, L ,0.5
13029	KM-13029-7010	Engine Piston, L, 0.5
13031	KM-13031-7084	Complete Crankshaft
13251	KM-13251-7025	Connecting Rod Assembly
92033	KM-92033-7016	Snap Ring
92151	KM-92151-7017	Bolt, 6 X 35

Kawasaki FR691V-AS05 Cylinder/Crankcase

E0110-A630A




Kawasaki FR691V-AS05 Cylinder/Crankcase

Ref.	Part Number	Description
11004	KM-11004-7026	Head Gasket
11008	KM-11008-7039	Complete Cylinder Head, #1
11008A	KM-11008-7040	Complete Cylinder Head, #2
11022	KM-11022-7019	Rocker Case, #1
11022A	KM-11022-7020	Rocker Case, #2
11061	KM-11061-7083	Rocker Case Gasket
11061A	KM-11061-7084	Breather Gasket
13272	KM-13272-7004	Breather Plate
14091	KM-14091-7064	Breather Cover
16126	KM-16126-7020	Breather Valve
32154	KM-32154-7019	Pipe
32155	KM-32155-7003	Breather Pipe
49015	KM-49015-7079	Crankcase Cover
49120	KM-49120-7122	Complete Crankcase
59071	KM-59071-2079	Joint
92043	KM-92043-1263	Pin
92049	KM-92049-7001	Oil Seal, RVC 26 x 11 x 10.2
92049A	KM-92049-7005	Oil Seal, SO 8 x 14 x 5 HS
92049B	KM-92049-7010	Oil Seal, SD 35 x 48 x 8 RHS
92049C	KM-92049-7028	Oil Seal, 38 x 62 x 8 MTCLV
92066	KM-92066-7023	Plug
92066A	KM-92066-7026	Plug
92153	KM-92153-7043	Bolt, 6 x 12
92153A	KM-92153-7054	Bolt, 8 x 50
130	KM-130AA0625	Flanged Bolt, 6 x 25
130A	KM-130CA1050	Flanged Bolt, 10 x 50
130B	KM-130CA1065	Flanged Bolt, 10 x 65
172	KM-172BA0818	Stud Bolt, 8 x 18
214	KM-214AA0408	Pan Screw +-, 4 x 8
670	KM-670B2011	O-Ring, 11mm

Kawasaki FR691V-AS05 Lubrication Equipment


E0140-A447A



Ref.	Part Number	Description
13272	KM-13272-7011	Rotor Plate
14075	KM-14075-7013	Oil Gauge Cap Assembly
16154	KM-16154-7010	Outer Pump Rotor
16154A	KM-16154-7011	Inner Pump Rotor
49065	KM-49065-7006	Oil Filter
49065A	KM-49065-7007	Oil Filter
59231	KM-59231-7016	Filler
92066	KM-92066-7003	Plug
92066A	KM-92066-7028	Plug
92140	KM-92140-7003	Ball
92145	KM-92145-7002	Spring
92153	KM-92153-7008	Bolt
92153A	KM-92153-7043	Bolt, 6 X 12
555	KM-555A0420	Spring Pin, 4 X 20
670	KM-670D2016	O-Ring, 16mm

Kawasaki FR691V-AS05 Cooling Equipment


E0150-A873A



Ref.	Part Number	Description
13070	KM-13070-7019	Cooling Air Guide
13272	KM-13272-7006	Fan Plate
14037	KM-14037-70089H	Screen
23062	KM-23062-7005	Complete Bracket
49089	KM-49089-7079	Engine Shroud
49089A	KM-49089-7080	Engine Shroud
59041	KM-59041-7014	Fan
59066	KM-59066-7046	Fan Housing
92009	KM-92009-2303	Screw
92026	KM-92026-7007	Spacer
92151	KM-92151-7012	Bolt, 6 X 12
92153	KM-92153-7007	Bolt
92153A	KM-92153-7043	Bolt, 6 X 12

Kawasaki FR691V-AS05 Electric Equipment

E0160-B284A





Ref.	Part Number	Description
13272	KM-13272-7012	Plate
21066	KM-21066-7017	Voltage Regulator
21171	KM-21171-7041	Ignition Coil Assembly
21193	KM-21193-7038	Flywheel Assembly
26011	KM-26011-7025	Lead Wire, L = 95
26031	KM-26031-7040	Harness
26031A	KM-26031-7041	Harness
26031B	KM-26031-7044	Harness
59031	KM-59031-7017	Charging Coil
92009	KM-92009-2303	Screw

Ref.	Part Number	Description
92009A	KM-92009-2308	Screw
92066	KM-92066-7026	Plug
92070	759-3339	Spark Plug
92072	KM-92072-7003	Band
92151	KM-92151-2097	Bolt, 12 X 30
92171	KM-92171-7008	Clamp
92172	KM-92172-7018	Screw, 5 X 20
92200	KM-92200-7002	Washer
130	KM-130AA0620	Flanged Bolt, 6 X 20
510	KM-510A5100	Woodruff Key

Kawasaki FR691V-AS05 Control Equipment

E0170-A652A




Ref.	Part Number	Description
13107	KM-13107-7047	Shaft
13271	KM-13271-7038	Plate
16171	KM-16171-7022	Link
39129	KM-39129-7028	Governor Spring
49103	KM-49103-7014	Governor Arm
49103A	KM-49103-7015	Governor Arm
49113	KM-49113-7050	Complete Control Panel
92145	KM-92145-7057	Spring
92145A	KM-92145-7058	Spring
92150	KM-92150-2182	Bolt, 5 X 18

Ref.	Part Number	Description
92153	KM-92153-0009	Bolt, 6 X 12
92153A	KM-92153-7033	Bolt, 6 X 35
92153B	KM-92153-7043	Bolt, 6 X 12
92170	KM-92170-7001	Clamp
92172	KM-92172-7035	Screw, 5 X 30
214	KM-214AA0408	Pan Screw +-, 4 X 8
311	KM-311AA0600	Hex Nut, 6mm
312	KM-312AA0500	Hex Nut, 5mm
411	KM-411AA0600	Plain Washer, 6mm

Kawasaki FR691V-AS05 Carburetor

E0180-A778A




Ref.	Part Number	Description
11061	KM-11061-7009	Chamber Gasket
11061A	KM-11061-7010	Screw Gasket
11061B	KM-11061-7085	Manifold Gasket
11061C	KM-11061-7087	Insulator Gasket
11061D	KM-11061-7088	Insulator/Manifold Gasket
13107	KM-13107-7018	Shaft
15004	KM-15004-7063	Carburetor Assembly
16014	KM-16014-7010	Pilot Air Screw
16020	KM-16020-7003	Float Chamber
16025	KM-16025-7017	Throttle Valve
16030	KM-16030-7003	Float Valve
16031	KM-16031-7002	Float
16041	KM-16041-7050	Choke Carburetor Shaft
16041A	KM-16041-7051	Throttle Carburetor Shaft
16073	KM-16073-7013	Insulator
16186	KM-16186-7006	Choke Valve Assembly

Ref.	Part Number	Description
21188	KM-21188-7002	Solenoid
39074	KM-39074-7001	Throttle Lever Assembly
49121	KM-49121-7018	Main Nozzle
59076	KM-59076-7019	Intake Manifold
92009	KM-92009-2083	Screw
92009A	KM-92009-2349	Screw
92009B	KM-92009-2402	Screw
92063	KM-92063-7141	Main Jet, #122
92063A	KM-92063-7142	Main Jet, #124
92063B	KM-92063-7149	Main Jet, #120
92081	KM-92081-2234	Spring
92093	KM-92093-2100	Seal
92093A	KM-92093-7003	Seal
92145	KM-92145-2122	Spring
130	KM-130AA0630	Flanged Bolt, 6 X 30
172	KM-172BA06115	Stud Bolt, 6 X 115

Kawasaki FR691V-AS05 Air Filter/Muffler


E0190-B094A



Ref.	Part Number	Description
11011	KM-11011-7054	Air Filter Case
11013	KM-11013-7047	Air Filter Element
11060	KM-11060-7016	Muffler Gasket
11061	KM-11061-7086	Carburetor/Pipe Intake Gasket
11065	KM-11065-7023	Cap
16060	KM-16060-7038	Intake Pipe
42036	KM-42036-7017	Breather Sleeve
92009	KM-92009-2303	Screw
92015	KM-92015-1367	Nut
92171	KM-92171-7007	Clamp
92173	KM-92173-7003	Clamp
92192	KM-92192-7146	Tube, 12.6 X 18.6 X 118
92192A	KM-92192-7151	Air Filter Tube
92210	KM-92210-7027	Nut, M8
461	KM-461DA0800	Spring Washer, 8mm

Kawasaki FR691V-AS05 Fuel Tank/Fuel Valve


E0200-A679A



Ref.	Part Number	Description
42036	KM-42036-7015	Sleeve
49019	KM-49019-7005	Fuel Filter
49040	KM-49040-7008	Fuel Pump
92009	KM-92009-2303	Screw
92170	KM-92170-2009	Clamp
92171	KM-92171-7008	Clamp
92192	KM-92192-7145	Tube, 6.35 X 12.7 X 185
92192A	KM-92192-7148	Tube, 6.4 X 12.7 X 150
92192B	KM-92192-7150	Tube, 6.35 X 12.7 X 390


Kawasaki FR691V-AS05 Carburetor

E0210-A452A




Ref.	Part Number	Description
16146	KM-16146-7027	Cover Assembly
16146A	KM-16146-7028	Cover Assembly
21080	KM-21080-7006	Armature
21163	KM-21163-7024	Electric Starter
27012	KM-27012-7004	Hook
32085	KM-32085-7004	Stopper
59051	KM-59051-7034	Spur Gear
92093	KM-92093-7007	Seal
92145	KM-92145-7060	Spring
92154	KM-92154-7001	Bolt
92210	KM-92210-7017	Nut
92210A	KM-92210-7036	Nut
130	KM-130AA0840	Flanged Bolt, 8 X 40

56033




56070



Ref.	Part Number	Description
56033	KM-56033-7001	Manual Label
56070	KM-56070-7001	Warning Label


Kawasaki FH721-BW04 Cylinder & Crankcase



Kawasaki FH721-BW04 Cylinder & Crankcase


Ref.	Part Number	Description
1.	KM-11004-7006	Head Gasket
2.	KM-11008-7023	Complete Cylinder Head, #2
3.	KM-11008-7024	Complete Cylinder Head, #1
4.	KM-11022-7002	Rocker Case
5.	KM-11060-7012	Crankcase Cover Gasket
6.	KM-11060-7013	Rocker Case Gasket
7.	KM-11060-7014	Breather Gasket
8.	KM-13271-7006	Plate
9.	KM-14091-7004	Cover
10.	KM-16126-7001	Valve
11.	KM-49015-7064	Crankcase Cover
12.	KM-49109-7003	Breather Element
13.	KM-49120-7093	Crankcase Complete
14.	KM-59066-7002	Plug
15.	KM-92033-7004	Snap Ring
16.	KM-92043-7001	Pin
17.	KM-92049-7001	Oil Seal, RVC2 6 x 11 x 10.2
18.	KM-92049-7005	Oil Seal, SO 8 x 14 x 5 HS
19.	KM-92049-7011	Oil Seal, SD 35 x 62 x 8 L HS
20.	KM-92049-7014	Oil Seal, SD 35 x 52 x 7 R HS
21.	KM-92153-7043	Bolt
22.	KM-130AA0640	Flange Bolt
23.	KM-92153-7054	Bolt
24.	KM-172BA0818	Flange Bolt
25.	KM-214AA0408	Stud Bolt
26.	KM-214B0408	Pan Screw

Kawasaki FH721-BW04 Pistons & Crankshaft



Ref.	Part Number	Description
1.	KM-13001-7007	Engine Piston
—	KM-13029-7003	Engine Piston, L 0.50
2.	KM-13002-7001	Piston Pin
3.	KM-13008-6058	Piston Ring Set
—	KM-13025-7002	Piston Ring Set, L 0.50
4.	KM-13031-7048	Crankshaft
5.	KM-13251-7016	Connecting Rod
6.	KM-92033-7002	Snap Ring
7.	KM-92151-7017	Bolt, 6 x 35


Kawasaki FH721-BW04 Camshaft & Valves



Ref.	Part Number	Description
1.	KM-12004-7002	Intake Valve
2.	KM-12005-7004	Exhaust Valve
3.	KM-12009-7001	Valve Spring Retainer
4.	KM-12011-2056	Collet
5.	KM-12017-7007	Rocket Arm
6.	KM-12032-7001	Tappet
7.	KM-13070-7004	Guide
8.	KM-13070-7007	Guide
9.	KM-13116-7002	Push Rod
10.	KM-13271-7007	Plate
11.	KM-13271-7021	Governor Plate


Ref.	Part Number	Description
12.	KM-42036-7010	Sleeve
13.	KM-49078-7002	Valve Spring
14.	KM-99999-7074	Complete Camshaft
15.	KM-92009-2341	Screw
16.	KM-92015-2253	Nut
17.	KM-92033-7001	Snap Ring
18.	KM-92140-7002	Ball
19.	KM-92145-7001	Spring
20.	KM-92153-7019	Bolt
21.	KM-92200-7001	Washer

Kawasaki FH721-BW04 Lubrication



Ref.	Part Number	Description
1	KM-13107-7009	Shaft
2	KM-13271-7005	Plate
3	KM-14075-7008	Dipstick Assembly
4	KM-16154-7007	Pump Rotor (In)
5	KM-16154-7008	Pump Rotor (Out)
6	KM-39067-7008	Oil Cooler
7	KM-49065-2078	Oil Filter
8	KM-49065-7003	Oil Filter
9	KM-59051-7011	Spur Gear


Ref.	Part Number	Description
10	KM-59071-7009	Join
11	KM-59231-7006	Dipstick/Oil Fill Tube
12	KM-92043-7003	Pin
13	KM-92055-7006	O-Ring
14	KM-92066-7003	Plug
15	KM-92140-7003	Ball
16	KM-92145-7002	Spring
17	KM-92153-7043	Flange Bolt
18	KM-670D2016	O-Ring, 16mm




Ref.	Part Number	Description
1.	KM-13270-7007	Plate
2.	KM-14037-70089H	Screen
3.	KM-14091-7002	Cover
4.	KM-23062-7005	Grass Screen Bracket
5.	KM-49089-7004	Engine Shroud
6.	KM-49089-7005	Engine Shroud
7.	KM-49089-7040	Engine Shroud
8.	KM-59066-7004	Housing Fan
9.	KM-55020-7007	Guard
10.	KM-59041-7003	Impeler Fan

Ref.	Part Number	Description
11.	KM-92004-7006	Stud
12.	KM-92026-7007	Shim Spacer
13.	KM-92153-7007	Bolt
14.	KM-92153-7008	Bolt
15.	KM-92210-0003	Nut
16.	KM-92172-7029	Socket Screw
17.	KM-130AA0816	Flange Bolt
18.	KM-311B0600	Hex Nut
19.	KM-92153-7043	Bolt, 6 x 12

Kawasaki FH721-BW04 Flywheel & Electrical



Ref.	Part Number	Description
1.	KM-21066-7011	Voltage Regulator
2.	KM-21171-7034	Ignition Coil
3.	KM-21193-7019	Flywheel
4.	KM-26030-7002	Harness
5.	KM-26031-7003	Harness
6.	KM-59031-7009	Charging Coil
7.	KM-92004-7009	Stud
8.	KM-92009-2308	Screw
9.	KM-BPR4ES	Spark Plug (NGK)
10.	KM-92072-7003	Band
11.	KM-92151-2097	Bolt, 12 x 30
12.	KM-92200-7002	Washer
13.	KM-130AA0620	Flange Bolt, 6 x 20
14.	KM-92172-7018	Screw, 5 x 20
15.	KM-311B0600	Hex Nut
16.	KM-510A5100	Woodruff Key
17.	KM-27010-7002	Oil Pressure Switch



Ref.	Part Number	Description
1.	KM-13107-7013	Shaft
2.	KM-13271-7032	Plate
3.	KM-16169-7006	Choke Link
4.	KM-16171-7004	Link
5.	KM-39129-7004	Governor Spring
6.	KM-49103-7004	Governor Arm
7.	KM-49113-7017	Control Panel
8.	KM-92145-7004	Spring
9.	KM-92145-7005	Spring


Ref.	Part Number	Description
10.	KM-92145-7034	Spring
11.	KM-92150-2182	Bolt, 5 x 18
12.	KM-92151-7014	Bolt, 5 x 30
13.	KM-92153-7033	Bolt, 6 x 35
14.	KM-92170-7001	Clamp
15.	KM-92153-7043	Bolt, 6 x 12
16.	KM-214AA0408	Pan Screw, 4 x 8
17.	KM-311B0600	Hex Nut
18.	KM-411B0600	Plain Washer

Kawasaki FH721-BW04 Carburetor


Ref.	Part Number	Description
1.	KM-11009-2056	Gasket
2.	KM-11060-7009	Air Filter Gasket
3.	KM-11060-7011	Manifold Gasket
4.	KM-11060-7024	Carburetor Gasket
5.	KM-11061-7037	Gasket
6.	KM-11061-7038	Gasket
7.	KM-11061-7039	Gasket
8.	KM-14091-7031	Cover
9.	KM-172BA06105	Stud Bolt
10.	KM-16025-7003	Throttle Valve
11.	KM-16030-7004	Float Valve
12.	KM-16031-7003	Float
13.	KM-16041-7021	Carburetor Shaft
14.	KM-16041-7025	Carburetor Shaft
15.	KM-16073-7005	Insulator
16.	KM-16126-7015	Choke Valve
17.	KM-16184-7017	Float Chamber
18.	KM-16187-7002	Jet Needle
19.	KM-21188-7003	Solenoid
20.	KM-59076-7011	Intake Manifold
21.	KM-92009-7003	Screw
22.	KM-92009-7004	Screw

Ref.	Part Number	Description
23.	KM-92009-7006	Drain Screw
24.	KM-92026-7011	Spacer
25.	KM-92043-7014	Pin
26.	KM-92055-7012	O-Ring
27.	KM-92055-7013	O-Ring
28.	KM-92055-7016	O-Ring
29.	KM-92063-7051	Main Jet, #104
—	KM-92063-7075	Main Jet, #101, 3280 FT
—	KM-92063-7076	Main Jet, #098, 6560 FT
30.	KM-92063-7056	Main Jet, #102
—	KM-92063-7079	Main Jet, #099, 3280 FT
—	KM-92063-7080	Main Jet, #096, 6560 FT
31.	KM-92066-7009	Expansion Plug
32.	KM-92093-7001	D Seal Seal, 5.9
33.	KM-92093-7002	D Seal, 6.9
34.	KM-92145-7010	Spring
35.	KM-92145-7011	Spring
36.	KM-92152-7005	Collar
37.	KM-92172-7005	Screw
38.	KM-92172-7006	Screw
39.	KM-130AA0620	Flange Bolt

Kawasaki FH721-BW04 Fuel Pump & Filter




Ref.	Part Number	Description
1.	KM-23062-70049H	Bracket
2.	KM-49019-7001	Fuel Filter
3.	KM-49040-7001	Fuel Pump
4.	KM-92170-2009	Clamp
5.	KM-92170-7003	Clamp
6.	KM-92192-7037	Tube, 6.35 x 12.7 x 160
7.	KM-42036-7008	Sleeve
8.	KM-92191-7027	Tube
9.	KM-130AA0616	Flange Bolt, 6 x 16
10.	KM-130AA0620	Flange Bolt, 6 x 20
11.	KM-92192-7103	Fuel Pump
12.	KM-92170-2088	Clamp




Ref.	Part Number	Description
1.	KM-13101-7003	Gear Assembly
2.	KM-21039-7004	Brush
3.	KM-21080-7001	Armature
4.	KM-21163-7029	Starter Assembly
5.	KM-39184-7004	Bracket
6.	KM-92151-7013	Bolt
7.	KM-130AA0816	Flange Bolt

Kawasaki FH721-BW04 Air Filter



Ref.	Part Number	Description
1.	KM-11011-7042	Air Filter Case
2.	KM-11013-7009	Air Filter Element
3.	KM-11013-7027	Air Filter Element
4.	KM-16060-7001	Intake Pipe
5.	KM-92015-1193	Nut
6.	KM-92171-7013	Clamp
7.	KM-42036-7002	Sleeve
8.	KM-92191-7006	Tube
9.	KM-92210-7004	Nut
10.	KM-92210-7019	Nut
11.	KM-130B06105	Flange Bolt




777D10680



777I22884



777I22885



777I22886



777I22888



777D11853



777D11852



777D10716



777D10658



777D10717



777I22489



777I22465 (Under Seat)



777D10624



Deck Labels

777D11758




777S30503



777S32598



777I22282




777I22764



777I22763



777S32978





To order replacement parts, call a Customer Support Representative at (800) 965-4CUB.
Locate your nearest Cub Cadet dealer at (877) 282-8684
or visit www.cubcadet.com to find the nearest Cub Cadet dealer in your area.

CUB CADET LLC, P.O. BOX 361131 CLEVELAND, OHIO 44136-0019
